


Open eVision



This documentation is provided with **Open eVision 24.02.0** (doc build **1198**).
www.euresys.com

This documentation is subject to the General Terms and Conditions stated on the website of **EURESYS S.A.** and available on the webpage <https://www.euresys.com/en/Menu-Legal/Terms-conditions>. The article 10 (Limitations of Liability and Disclaimers) and article 12 (Intellectual Property Rights) are more specifically applicable.

Contents

1. Basic Types	7
1.1. Loading and Saving Images	7
1.2. Interfacing Third-Party Images	7
1.3. Retrieving Pixel Values	8
1.4. Importing Bitmap from the Resources	8
1.5. ROI Placement	9
1.6. Vector Management	9
1.7. Exception Management	10
2. ERegion	11
2.1. Basic Usage	11
2.2. Prepare Once, Use Multiple Times	11
2.3. Combine Regions	12
2.4. Tool Chain	12
3. EGrabberBridge	13
3.1. Using EGrabberBridge	13
3.2. Using EGrabberBridge with Format Conversion	13
3.3. Managing EGrabber Parameters	14
4. VimbaXBridge	16
4.1. Using VimbaXBridge	16
5. EasyImage	17
5.1. Thresholding	17
Single Thresholding	17
Double Thresholding	17
Histogram-Based Single Thresholding	18
Histogram-Based Double Thresholding	18
5.2. Arithmetic and Logic Operations	19
5.3. Convolution	20
Pre-Defined Kernel Filtering	20
User-Defined Kernel Filtering	20
5.4. Non-Linear Filtering	21
Morphological Filtering	21
Hit-and-Miss Transform	21
5.5. Vector Operations	22
Path Sampling	22
Profile Sampling	22
5.6. Statistics	23
Image Statistics	23
Sliding Windows Statistics	23
Histogram-Based Statistics	24
5.7. Noise Reduction by Integration	24
Temporal Noise Reduction	24
Recursive Average	25
5.8. Feature Point Detectors	26
Harris Corner Detector	26
Canny Edge Detector	26
5.9. Using Flexible Masks	27
5.10. Warping	27
Performing a Ring Warping	27
Performing an Inverse Warping	28
5.11. Fourier Transforms	28
Performing a Direct Fourier Transform	28
Performing an Inverse Fourier Transform	28

6. EasyColor	30
6.1. Colorimetric Systems Conversion	30
6.2. Color Components	30
6.3. White Balance	31
6.4. Pseudo-Coloring	31
6.5. Bayer Pattern Decoding	32
7. Deep Learning Tools	33
7.1. Creating a Dataset and Training a Classifier	33
7.2. Loading a Classifier and Classifying a New Image	33
7.3. Using Multithreading for Classification	34
7.4. Loading an Unsupervised Segmenter and Segmenting an Image	36
8. EasyObject	38
8.1. Constructing the Blobs	38
Image Encoder	38
Image Segmenter	38
Holes Extraction	39
Continuous Mode	40
8.2. Computing Blobs Features	40
8.3. Selecting and Sorting Blobs	41
8.4. Using Flexible Masks	42
Constructing Blobs	42
Generating a Flexible Mask from an Encoded Image	42
Generating a Flexible Mask from a Blob Selection	43
8.5. Using the Object Template Matcher	43
9. EasyMatch	45
9.1. Pattern Learning	45
9.2. Setting Search Parameters	45
9.3. Pattern Matching and Retrieving Results	46
9.4. Pattern Learning with ERegion	46
10. EasyFind	48
10.1. Pattern Learning	48
10.2. Setting Search Parameters	48
10.3. Pattern Finding and Retrieving Results	49
10.4. Learning Using a DXF File	49
10.5. Learning Using an EPolygonShape	50
11. EasyGauge	51
11.1. Point Location	51
11.2. Line Fitting	51
11.3. Circle Fitting	52
11.4. Rectangle Fitting	53
11.5. Wedge Fitting	53
11.6. Gauge Grouping	54
Gauge Hierarchy	54
Complex Measurement	55
11.7. Calibration using EWorldShape	55
Calibration by Guesswork	55
Landmark-Based Calibration	56
Dot Grid-Based Calibration	56
Coordinates Transform	57
Image Unwarping	57
12. EasyOCR	59
12.1. Learning Characters	59
12.2. Recognizing Characters	59
13. EasyOCR2	61

13.1. Detecting Characters	61
13.2. Learning Characters	61
13.3. Reading Characters	62
Reading Using TrueType Fonts	62
Reading Using EOCR2 Character Database	63
Reading Using EOCR2 Model File	64
13.4. View Bitmap	64
14. EasyBarCode	65
14.1. Reading a Bar Code	65
14.2. Reading a Bar Code Following a Given Symbology	65
14.3. Reading a Bar Code of Known Location	66
14.4. Reading a Mail Bar Code	66
15. EasyBarCode2	68
15.1. Reading a Bar Code	68
15.2. Reading a Bar Code of a Specific Symbology	68
15.3. Reading a Grid of Bar Codes	69
15.4. Learning a Bar Code	69
15.5. Grading a Bar Code	69
16. EasyMatrixCode	71
16.1. Reading a Data Matrix Code	71
16.2. Learning a Data Matrix Code	71
16.3. Tuning the Search Parameters	72
16.4. Grading a Data Matrix Code	73
17. EasyMatrixCode2	74
17.1. Reading Data Matrix Codes	74
17.2. Learning a Data Matrix Code	74
17.3. Reading a Grid of Matrix Codes	75
17.4. Grading a Data Matrix Code	75
17.5. Asynchronous Processing	76
18. EasyQRCode	78
18.1. Reading QR Codes	78
18.2. Reading a Grid of QR Codes	78
18.3. Grading a QR Code	78
18.4. Retrieving Information of a QR Code	79
18.5. Tuning the Search Parameters	79
18.6. Retrieving the Decoded String (Simple)	80
18.7. Retrieving the Decoded String (Safe)	80
18.8. Retrieving the Decoded Data (Advanced)	81
19. Easy3D	83
19.1. Using EFilters to Remove the Noise on a ZMap Based on the Standard Deviation	83
19.2. Using EFilters to Remove the Noise on a ZMap Based on the Derivation from Neighborhood	83
19.3. Reducing the Size of a Cloud with Random Decimation	84
19.4. Reducing the Size of a Cloud with Grid Decimation	84
19.5. Using Photometric Stereo	84
19.6. Using Flat Images to Improve Photometric Stereo	85
19.7. Performing Plane Leveling on Point Clouds	86
19.8. Using an ERegion to Crop a ZMap	86
19.9. Add an Attribute to an EPointCloud with Initial Data	86
19.10. Add an Attribute to an EPointCloud without Initial Data	87
19.11. Retrieve an Attribute from an EPointCloud	87
20. Easy3DObject	88
20.1. Extracting 3D Objects with a Selection Criterion	88
20.2. Inspecting a Feature from the List of E3DObjects	88

20.3. Drawing a 2D Feature from the List of E3DObjects	88
20.4. Drawing 3D Features from a List of E3DObjects	89
21. Easy3DMatch	90
21.1. E3DAligner Minimal Code	90
21.2. E3DAligner Reprojection Plane	90
21.3. E3DAlignment Align Sample	91
21.4. E3DComparer Minimal Sample	91
21.5. E3DComparer Advanced Sample	92
21.6. E3DMatcher Minimal Sample	92
21.7. E3DMatcher Advanced Sample	93
21.8. EPointCloudMerger Sample	94

1. Basic Types

1.1. Loading and Saving Images

Functional Guide | Reference: [Load](#), [Save](#), [SaveJpeg](#)

```
////////////////////////////////////  
// This code snippet shows how to load and save an image. //  
////////////////////////////////////  
  
// Images constructor  
EImageBW8 srcImage;  
EImageBW8 dstImage;  
  
// Load an image file  
srcImage.Load("mySourceImage.bmp");  
  
// ...  
  
// Save the destination image into a file  
dstImage.Save("myDestImage.bmp");  
  
// Save the destination image into a jpeg file  
// The default compression quality is 75  
dstImage.Save("myDestImage.jpg");  
  
// Save the destination image into a jpeg file  
// set the compression quality to 50  
dstImage.SaveJpeg("myDestImage50.jpg", 50);
```

1.2. Interfacing Third-Party Images

Functional Guide | Reference: [SetImagePtr](#)

```
////////////////////////////////////  
// This code snippet shows how to link an Open eVision image //  
// to an externally allocated buffer. //  
////////////////////////////////////  
  
// Images constructor  
EImageBW8 srcImage;  
  
// Size of the third-party image  
int sizeX;  
int sizeY;  
  
//Pointer to the third-party image buffer  
EBW8* imgPtr;  
  
// ...  
  
// Link the Open eVision image to the third-party image
```

```
// Assuming the corresponding buffer is aligned on 4 bytes
srcImage.SetImagePtr(sizeX, sizeY, imgPtr);
```

1.3. Retrieving Pixel Values

Functional Guide | Reference: [GetImagePtr](#)

```
////////////////////////////////////
// This code snippet shows the recommended method (fastest) //
// to access the pixel values in a BW8 image //
////////////////////////////////////

EImageBW8 img;

OEV_UINT8* pixelPtr;
OEV_UINT8* rowPtr;
OEV_UINT8 pixelValue;
OEV_UINT32 rowPitch;
int x, y;

rowPtr = reinterpret_cast <OEV_UINT8*>(img.GetImagePtr());
rowPitch = img.GetRowPitch();

for (y = 0; y < height; y++)
{
    pixelPtr = rowPtr;

    for (x = 0; x < width; x++)
    {
        pixelValue = *pixelPtr;

        // Add your pixel computation code here

        *pixelPtr = pixelValue;
        pixelPtr++;
    }

    rowPtr += rowPitch;
}
}
```

1.4. Importing Bitmap from the Resources

Functional Guide | Reference: [SetImagePtr](#)

```
////////////////////////////////////
// This code snippet shows how to import a bitmap from //
// the resources. //
////////////////////////////////////

// Get the bitmap
HBITMAP hbitmap = (HBITMAP)LoadImage(GetModuleHandle(NULL), MAKEINTRESOURCE(IDB_BITMAP1), IMAGE_BITMAP, 0, 0,
LR_CREATEDIBSECTION);
BITMAP bitmap;
GetObject(hbitmap, sizeof(bitmap), (LPVOID)&bitmap);

int width = bitmap.bmWidth;
```



```

int height = bitmap.bmpHeight;
UINT8* buffer = reinterpret_cast<UINT8*>(bitmap.bmpBits);

EImageC24 image(width, height);

for (int y = 0; y < height; ++y)
{
    // Copy the entire row
    memcpy(image.GetImagePtr(0, height - 1 - y), buffer, 3 * width);
    buffer += 3 * width;
}

```

1.5. ROI Placement

Functional Guide | Reference: [Attach](#), [SetPlacement](#)

```

////////////////////////////////////
// This code snippet shows how to attach an ROI to an image //
// and set its placement.                                     //
////////////////////////////////////

// Image constructor
EImageBW8 parentImage;

// ROI constructor
EROIBW8 myROI;

// ...

// Attach the ROI to the image
myROI.Attach(&parentImage);

//Set the ROI position
myROI.SetPlacement(50, 50, 200, 100);

```

1.6. Vector Management

Functional Guide | Reference: [Empty](#), [AddElement](#)

```

////////////////////////////////////
// This code snippet shows how to create a vector, fill it //
// and retrieve the value of a given element.               //
////////////////////////////////////

// EBW8Vector constructor
EBW8Vector ramp;

// Clear the vector
ramp.Empty();

// Fill the vector with increasing values
for(int i= 0; i < 128; i++)
{
    ramp.AddElement((EBW8)i);
}

```

```
// Retrieve the 10th element value
EBW8 value= ramp[9];
```

1.7. Exception Management

Functional Guide | Reference: [GetPixel](#), [What](#)

```
////////////////////////////////////
// This code snippet shows how to manage //
// Open eVision exceptions.             //
////////////////////////////////////

try
{
    // Image constructor
    EImageC24 srcImage;

    // ...

    // Retrieve the pixel value at coordinates (56, 73)
    EC24 value= srcImage.GetPixel(56, 730);
}

catch(Euresys::Open_eVision_1_1::EException exc)
{
    // Retrieve the exception description
    std::string error = exc.What();
}
```

2. ERegion

See also: [Arbitrary-Shaped ROI \(ERegion\)](#) / **example:** [Inspecting Pads Using Regions](#)

2.1. Basic Usage

```
////////////////////////////////////  
// This code snippet shows how to perform a threshold on a //  
// circular region in an image. //  
////////////////////////////////////  
  
// Image constructors  
EImageBW8 srcImage;  
EImageBW8 dstImage;  
  
//...  
  
// Create the region  
ECircleRegion circleRegion(center, radius);  
  
// Threshold the image  
EasyImage::Threshold(&srcImage, circleRegion, &dstImage);
```

2.2. Prepare Once, Use Multiple Times

```
////////////////////////////////////  
// This code snippet shows how to perform a threshold on a //  
// circular region in multiple image while preparing it //  
// only once. //  
////////////////////////////////////  
  
// Image constructors  
EImageBW8 srcImage[10];  
EImageBW8 dstImage[10];  
  
//...  
  
// Create the region  
ECircleRegion circleRegion(center, radius);  
  
// Prepare the region  
circleRegion.Prepare(srcImage[0]);  
  
// Threshold the images  
for (int i = 0; i < 10; i++)  
    EasyImage::Threshold(&srcImage[i], circleRegion, &dstImage[i]);
```

2.3. Combine Regions

```
////////////////////////////////////
// This code snippet shows how to perform a threshold on a //
// combined region in an image                               //
////////////////////////////////////

// Image constructors
EImageBW8 srcImage;
EImageBW8 dstImage;

//...

// Create first region
ECircleRegion circleRegion(center, radius);

// Create second region
ERectangleRegion rectangleRegion(center, width, height, angle);

// Combine regions
ERegion combinedRegion = ERegion::Union(circleRegion, rectangleRegion);

// Threshold the image
EasyImage::Threshold(&srcImage, combinedRegion, &dstImage);
```

2.4. Tool Chain

```
////////////////////////////////////
// This code snippet shows how to perform a threshold on a //
// region coming for a previous EasyFind process           //
////////////////////////////////////

// Image constructors
EImageBW8 findImage;
EImageBW8 srcImage;
EImageBW8 dstImage;

// EPatternFinder constructor
EPatternFinder finder;

//...

// Use EasyFind
std::vector<EFoundPattern> patterns = finder.Find(&findImage);

// Create region from found pattern
ERegion foundRegion(patterns[0]);

// Threshold the image
EasyImage::Threshold(&srcImage, foundRegion, &dstImage);
```

3. EGrabberBridge

See also: [EGrabberBridge - Using Images from Coaxlink](#)

3.1. Using EGrabberBridge

```

////////////////////////////////////
// This code snippet shows how to go from an EGrabber buffer to an //
// EGrabberImageBW8, compatible with Open eVision processing      //
////////////////////////////////////

// Construct the EGrabber objects.
EGenTL genTL;
EGrabber<CallbackOnDemand> grabber(genTL);

// Allocate one buffer
grabber.reallocBuffers(1);

//...

// Start the grabber acquisition of one buffer
grabber.start(1);

// Get the acquired buffer
ScopedBuffer buffer(grabber);

// Convert the ScopedBuffer to an Open eVision data container
EGrabberBridge::EGrabberImageBW8 image(buffer.getInfo());

// Stop the grabber
grabber.stop();

// Use the EGrabberImageBW8 as an Open eVision EImage Object
// Here an inversion of the image is performed
EImageBW8 invertedImage(image.GetWidth(), image.GetHeight());
EasyImage::Oper(EArithmeticLogicOperation_Invert, &image, &invertedImage);

```

3.2. Using EGrabberBridge with Format Conversion

```

////////////////////////////////////
// This code snippet shows how to go from an EGrabber buffer to an //
// EGrabberImageBW8, compatible with Open eVision processing using //
// format conversion////////////////////////////////////

// Construct the EGrabber objects.
// The FormatConverter will automatically convert the EGenTL buffer to
// the chosen Open eVision image type
EGenTL genTL;
EGrabber<CallbackOnDemand> grabber(genTL);

```

```

FormatConverter converter(genTL);

// Allocate one buffer
grabber.reallocBuffers(1);

//...

// Start the grabber acquisition of one buffer
grabber.start(1);

// Get the acquired buffer
ScopedBuffer buffer(grabber);

// Convert the ScopedBuffer to an Open eVision data container
EGrabberBridge::EGrabberImageBW8 image(converter, buffer.getInfo());

// Stop the grabber
grabber.stop();
// Use the EGrabberImageBW8 as an Open eVision EImage Object
// Here an inversion of the image is performed
EImageBW8 invertedImage(image.GetWidth(), image.GetHeight());
EasyImage::Oper(EArithmeticLogicOperation_Invert, &image, &invertedImage);

```

3.3. Managing EGrabber Parameters

```

/////////////////////////////////////////////////////////////////
// This code snippet shows how to go from an EGrabber buffer to an //
// EGrabberImageBW8, compatible with Open eVision
processing/////////////////////////////////////////////////////////////////

// Construct the EGrabber objects.
// The FormatConverter is optional and will automatically convert the EGenTL buffer to
// the chosen Open eVision image type
EGenTL genTL;
EGrabber<CallbackOnDemand> grabber(genTL);
FormatConverter converter(genTL);

// Allocate one buffer
grabber.reallocBuffers(1);

// ...

// Manage EGrabber features
// Get/set camera (RemoteModule) features of various types:
// string - integer - float.
// WARNING: The features might be specific to each camera
std::string pixelFormat = grabber.getString<RemoteModule>("PixelFormat");
grabber.setString<RemoteModule>("PixelFormat", "Mono8");

int64_t width = grabber.getInteger<RemoteModule>("Width");
grabber.setInteger<RemoteModule>("Width", 1024);

double exposureTime = grabber.getFloat<RemoteModule>("ExposureTime");
grabber.setFloat<RemoteModule>("ExposureTime", 60.0f);

// ...

// Start the grabber acquisition of one buffer
grabber.start(1);

```

```
// Get the acquired buffer
ScopedBuffer buffer(grabber);

// Convert the ScopedBuffer to an Open eVision data container
EGrabberBridge::EGrabberImageBW8 image(converter, buffer.getInfo());

// ...
```

4. VimbaXBridge

See also: [VimbaXBridge - Using Images from VimbaX Sources](#)

4.1. Using VimbaXBridge

```
////////////////////////////////////  
// This code snippet shows how to go from an VimbaX frame to an    //  
// EVimbaXImageBW8, compatible with Open eVision processing      //  
////////////////////////////////////  
// Get a EVimbaXImage from a C (VmbFrame_t) or C++ (VmbCPP::FramePtr)  
// frame pointer. If vmbTransform has been included, an automatic  
// pixel format conversion will be performed if needed.  
VimbaXBridge::EVimbaXImageBW8 image(frame);  
  
// Use the EVimbaXImageBW8 as an Open eVision EImage Object  
// Here an inversion of the image is performed EImageBW8  
EImageBW8 invertedImage(image.GetWidth(), image.GetHeight());  
EasyImage::Oper(EArithmeticLogicOperation_Invert, &image, &invertedImage);
```


5. EasyImage

5.1. Thresholding

Single Thresholding

Functional Guide | Reference: [SetSize](#), [Threshold](#)

```
////////////////////////////////////  
// This code snippet shows how to perform minimum residue //  
// thresholding, absolute thresholding and relative //  
// thresholding operations. //  
////////////////////////////////////  
  
// Images constructor  
EImageBW8 srcImage;  
EImageBW8 dstImage;  
  
// ...  
  
// Source and destination images must have the same size  
dstImage.SetSize(&srcImage);  
  
// Minimum residue thresholding (default method)  
EasyImage::Threshold(&srcImage, &dstImage);  
  
// Absolute thresholding (threshold = 110)  
EasyImage::Threshold(&srcImage, &dstImage, 110);  
  
// Relative thresholding (70% black, 30% white)  
EasyImage::Threshold(&srcImage, &dstImage, EThresholdMode_Relative, 0, 255, 0.7f);
```

Double Thresholding

Functional Guide | Reference: [DoubleThreshold](#)

```
////////////////////////////////////  
// This code snippet shows how to perform a thresholding //  
// operation based on low and high threshold values. //  
////////////////////////////////////  
  
// Images constructor  
EImageBW8 srcImage;  
EImageBW8 dstImage;  
  
// ...  
  
// Source and destination images must have the same size  
dstImage.SetSize(&srcImage);
```

```
// Double thresholding, low threshold = 50, high threshold = 150,
// pixels below 50 become black, pixels above 150 become white,
// pixels between thresholds become gray
EasyImage::DoubleThreshold(&srcImage, &dstImage, 50, 150, 0, 128, 255);
```

Histogram-Based Single Thresholding

Functional Guide | Reference: [Histogram](#), [HistogramThreshold](#)

```
////////////////////////////////////
// This code snippet shows how to perform a minimum residue //
// thresholding operation based on an histogram.           //
////////////////////////////////////

// Images constructor
EImageBW8 srcImage;
EImageBW8 dstImage;

// Histogram constructor
EBWHistogramVector histo;

// Variables
unsigned int thresholdValue;
float avgBelowThr, avgAboveThr;

// ...

// Compute the histogram
EasyImage::Histogram(&srcImage, &histo);

// Compute the single threshold (and the average pixel values below and above the threshold)
thresholdValue= EThresholdMode_MinResidue;
EasyImage::HistogramThreshold(&histo, thresholdValue, avgBelowThr, avgAboveThr);

// Source and destination images must have the same size
dstImage.SetSize(&srcImage);

// Perform the single thresholding
EasyImage::Threshold(&srcImage, &dstImage, thresholdValue);
```

Histogram-Based Double Thresholding

Functional Guide | Reference: [Histogram](#), [ThreeLevelsMinResidueThreshold](#), [DoubleThreshold](#)

```
////////////////////////////////////
// This code snippet shows how to perform a double thresholding //
// operation. The low and high threshold values are computed //
// according to the minimum residue method based on an histogram. //
////////////////////////////////////

// Images constructor
EImageBW8 srcImage;
EImageBW8 dstImage;

// Histogram constructor
EBWHistogramVector histo;

// Variables
```

```

EBW8 lowThr;
EBW8 highThr;
float avgBelowThr, avgBetweenThr, avgAboveThr;

// ...

// Compute the histogram
EasyImage::Histogram(&srcImage, &histo);

// Compute the low and high threshold values automatically
// (and the average pixel values below, between and above the threshold)
EasyImage::ThreeLevelsMinResidueThreshold(&histo, lowThr, highThr, avgBelowThr, avgBetweenThr, avgAboveThr);

// Source and destination images must have the same size
dstImage.SetSize(&srcImage);

// Perform the double thresholding
EasyImage::DoubleThreshold(&srcImage, &dstImage, lowThr.Value, highThr.Value);

```

5.2. Arithmetic and Logic Operations

Functional Guide | Reference: [Oper](#)

```

////////////////////////////////////
// This code snippet shows how to apply miscellaneous //
// arithmetic and logic operations to images.         //
////////////////////////////////////

// Images constructor
EImageBW8 srcGray0, srcGray1, dstGray;
EImageC24 srcColor, dstColor;

// ...

// All images must have the same size
dstGray.SetSize(&srcGray0);
// ...

// Subtract srcGray1 from srcGray0
EasyImage::Oper(EArithmeticLogicOperation_Subtract, &srcGray0, &srcGray1, &dstGray);

// Multiply srcGray0 by a constant value
EasyImage::Oper(EArithmeticLogicOperation_Multiply, &srcGray0, (EBW8)2, &dstGray);

// Add a constant value to srcColor
EasyImage::Oper(EArithmeticLogicOperation_Add, &srcColor, EC24(128,64,196), &dstColor);

// Erase (blacken) the destination image where the source image is black
EasyImage::Oper(EArithmeticLogicOperation_SetZero, &srcGray0, (EBW8)0, &dstGray);

```

5.3. Convolution

Pre-Defined Kernel Filtering

```

////////////////////////////////////
// This code snippet shows how to apply miscellaneous //
// convolution operations based on pre-defined kernels. //
////////////////////////////////////

// Images constructor
EImageBW8 srcImage;
EImageBW8 dstImage;

// ...

// Source and destination images must have the same size
dstImage.SetSize(&srcImage);

// Perform a Uniform filtering (5x5 kernel)
EasyImage::ConvolUniform(&srcImage, &dstImage, 2);

// Perform a Highpass filtering
EasyImage::ConvolHighpass1(&srcImage, &dstImage);

// Perform a Gradient filtering
EasyImage::ConvolGradient(&srcImage, &dstImage);

// Perform a Sobel filtering
EasyImage::ConvolSobel(&srcImage, &dstImage);

```

User-Defined Kernel Filtering

```

////////////////////////////////////
// This code snippet shows how to apply a convolution //
// operation based on a user-defined kernel. //
////////////////////////////////////

// Images constructor
EImageBW8 srcImage;
EImageBW8 dstImage;

// ...

// Create and define a user-defined kernel
// (Frei-Chen row gradient, positive only)
EKernel kernel;
kernel.SetKernelData(0.2929f, 0, -0.2929f,
                    0.4142f, 0, -0.4142f,
                    0.2929f, 0, -0.2929f);

// Source and destination images must have the same size
dstImage.SetSize(&srcImage);

// Apply the convolution kernel
EasyImage::ConvolKernel(&srcImage, &dstImage, &kernel);

```

5.4. Non-Linear Filtering

Functional Guide | [Reference](#)

Morphological Filtering

Functional Guide | Reference: [ErodeBox](#), [DilateBox](#), [OpenDisk](#)

```

////////////////////////////////////
// This code snippet shows how to apply miscellaneous //
// morphological filtering operations.                //
////////////////////////////////////

// Images constructor
EImageBW8 srcImage;
EImageBW8 dstImage;

// ...

// Source and destination images must have the same size
dstImage.SetSize(&srcImage);

// Perform an erosion (3x3 square kernel)
EasyImage::ErodeBox(&srcImage, &dstImage, 1);

// Perform a dilation (5x3 rectangular kernel)
EasyImage::DilateBox(&srcImage, &dstImage, 2, 1);

// Perform an Open operation (5x5 circular kernel)
EasyImage::OpenDisk(&srcImage, &dstImage, 2);

```

Hit-and-Miss Transform

Functional Guide | Reference: [SetValue](#), [HitAndMiss](#)

```

////////////////////////////////////
// This code snippet shows how to highlight the left corner //
// of a rhombus by means of a Hit-and-Miss operation.      //
////////////////////////////////////

// Images constructor
EImageBW8 srcImage;
EImageBW8 dstImage;

// ...

// Create and define a Hit-and-Miss kernel
// corresponding to the left corner of a rhombus
EHitAndMissKernel leftCorner(-1, -1, 1, 1);

// Left column of the kernel
leftCorner.SetValue(-1, 0, EHitAndMissValue_Background);

// Middle column of the kernel
leftCorner.SetValue(0, -1, EHitAndMissValue_Background);
leftCorner.SetValue(0, 0, EHitAndMissValue_Foreground);

```

```

leftCorner.SetValue(0, 1, EHitAndMissValue_Background);

// Right column of the kernel
leftCorner.SetValue(1, -1, EHitAndMissValue_Foreground);
leftCorner.SetValue(1, 0, EHitAndMissValue_Foreground);
leftCorner.SetValue(1, 1, EHitAndMissValue_Foreground);

// Source and destination images must have the same size
dstImage.SetSize(&srcImage);

// Apply the Hit-and-Miss kernel
EasyImage::HitAndMiss(&srcImage, &dstImage, leftCorner);

```

5.5. Vector Operations

Functional Guide | [Reference](#)

Path Sampling

Functional Guide | Reference: [Empty](#), [AddElement](#), [ImageToPath](#)

```

//////////////////////////////////////////////////////////////////
// This code snippet shows how to retrieve and store the //
// pixel values along a given path together with the //
// corresponding pixel coordinates. //
//////////////////////////////////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// ...

// Vector constructor
EBW8PathVector path;

// Path definition
path.Empty();
for (int i = 0; i < 100; i++)
{
    EBW8Path p;
    p.X = i;
    p.Y = i;
    p.Pixel = 128;
    path.AddElement(p);
}

// Get the image data along the path
EasyImage::ImageToPath(&srcImage, &path);

```

Profile Sampling

Functional Guide | Reference: [ImageToLineSegment](#), [LineSegmentToImage](#)

```

////////////////////////////////////
// This code snippet shows how to set, retrieve and store //
// the pixel values along a given line segment. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// ...

// Vector constructor
EBW8Vector profile;

// Get the image data along segment (10,510)-(500,40)
EasyImage::ImageToLineSegment(&srcImage, &profile, 10, 510, 500, 40);

// Set all these points to white (255) in the image
EasyImage::LineSegmentToImage(&srcImage, 255, 10, 510, 500, 40);

```

5.6. Statistics

Image Statistics

```

////////////////////////////////////
// This code snippet shows how to compute basic image statistics. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// ...

// Count the number of pixels above the threshold (128)
INT32 count;
EasyImage::Area(&srcImage, 128, count);

// Compute the pixels' average and standard deviation values
float stdDev, average;
EasyImage::PixelStdDev(&srcImage, stdDev, average);

// Compute the image gravity center (pixels above threshold)
float x, y;
EasyImage::GravityCenter(&srcImage, 128, x, y);

```

Sliding Windows Statistics

Functional Guide | Reference: [LocalAverage](#), [LocalDeviation](#)

```

////////////////////////////////////
// This code snippet shows how to perform sliding windows statistics. //
////////////////////////////////////

// Images constructor
EImageBW8 srcImage;

```

```

EImageBW8 dstImage0, dstImage1;

// ...

// All images must have the same size
dstImage0.SetSize(&srcImage);
dstImage1.SetSize(&srcImage);

// Local average in a 11x11 window
EasyImage::LocalAverage(&srcImage, &dstImage0, 5, 5);

// Local deviation in a 11x11 window
EasyImage::LocalDeviation(&srcImage, &dstImage1, 5, 5);

```

Histogram-Based Statistics

Functional Guide | Reference: [Histogram](#), [AnalyseHistogram](#)

```

////////////////////////////////////
// This code snippet shows how to compute statistics //
// based on an histogram. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// ...

// Histogram constructor
EBWHistogramVector histo;

// Compute the histogram
EasyImage::Histogram(&srcImage, &histo);

// Compute the average gray-level value
float average = EasyImage::AnalyseHistogram(&histo, EHistogramFeature_AveragePixelValue, 0, 255);

// Compute the gray-level standard deviation
float deviation = EasyImage::AnalyseHistogram(&histo, EHistogramFeature_PixelValueStdDev, 0, 255);

```

5.7. Noise Reduction by Integration

Functional Guide | [Reference](#)

Temporal Noise Reduction

Functional Guide | Reference: [Oper](#)

```

////////////////////////////////////
// This code snippet shows how to perform noise //
// reduction by temporal averaging. //
////////////////////////////////////

// Images constructor

```



```

EImageBW16 noisyImage, cleanImage;

// 16 bits work image used as an accumulator
EImageBW16 store;

// ...

// All images must have the same size
cleanImage.SetSize(&noisyImage);
store.SetSize(&noisyImage);

// Clear the accumulator image
EasyImage::Oper(EArithmeticLogicOperation_Copy, (EBW16)0, &store);

// Accumulation loop
int n;
for (n=0; n < 10; n++)
{
    // Acquire a new image into noisyImage
    // ...

    // Add this new noisy image into the accumulator
    EasyImage::Oper(EArithmeticLogicOperation_Add, &noisyImage, &store, &store);
}

// Perform noise reduction
EasyImage::Oper(EArithmeticLogicOperation_Divide, &store, (EBW16)n, &cleanImage);

```

Recursive Average

Functional Guide | Reference: [Oper](#), [SetRecursiveAverageLUT](#), [RecursiveAverage](#)

```

////////////////////////////////////
// This code snippet shows how to perform noise //
// reduction by recursive averaging.           //
////////////////////////////////////

// Images constructor
EImageBW8 noisyImage, cleanImage;

// 16 bits work image used as an accumulator
EImageBW16 store;

// ...

// All images must have the same size
cleanImage.SetSize(&noisyImage);
store.SetSize(&noisyImage);

// Clear the accumulator image
EasyImage::Oper(EArithmeticLogicOperation_Copy, (EBW16)0, &store);

// Prepare the transfer lookup table (reduction factor = 3)
EBW16Vector lut;
EasyImage::SetRecursiveAverageLUT(&lut, 3.f);

// Perform the noise reduction
EasyImage::RecursiveAverage(&noisyImage, &store, &cleanImage, &lut);

```

5.8. Feature Point Detectors

Harris Corner Detector

Functional Guide | Reference: [GetPointCount](#), [GetPoint](#)

```
////////////////////////////////////  
// This code snippet shows how to retrieve corners' coordinates //  
// by means of the Harris corner detector algorithm.           //  
////////////////////////////////////  
  
// Image constructor  
EImageBW8 srcImage;  
  
// ...  
  
// Harris corner detector  
EHarrisCornerDetector harris;  
EHarrisInterestPoints interestPoints;  
harris.SetIntegrationScale(2.f);  
  
// Perform the corner detection  
harris.Apply(srcImage, interestPoints);  
  
// Retrieve the number of corners  
unsigned int index = interestPoints.GetPointCount();  
  
// Retrieve the first corner coordinates  
EPoint point = interestPoints.GetPoint(0);  
float x = point.GetX();  
float y = point.GetY();
```

Canny Edge Detector

Functional Guide | Reference: [Apply](#)

```
////////////////////////////////////  
// This code snippet shows how to highlight edges //  
// by means of the Canny edge detector algorithm. //  
////////////////////////////////////  
  
// Images constructor  
EImageBW8 srcImage;  
EImageBW8 dstImage;  
  
// ...  
  
// Canny edge detector  
ECannyEdgeDetector canny;  
  
// Source and destination images must have the same size  
dstImage.SetSize(&srcImage);  
  
// Perform the edges detection  
canny.Apply(srcImage, dstImage);
```

5.9. Using Flexible Masks

Functional Guide | [Reference](#)

[Computing Pixels Average](#)

Functional Guide | Reference: [PixelAverage](#)

```

////////////////////////////////////
// This code snippet shows how to compute statistics //
// inside a region defined by a flexible mask. //
////////////////////////////////////

// Images constructor
EImageBW8 srcImage;
EImageBW8 mask;

// ...

// Compute the average value of the source image pixels
// corresponding to the mask do-care areas only
float average;
EasyImage::PixelAverage(&srcImage, &mask, average);

```

5.10. Warping

Performing a Ring Warping

```

// Create normal and warp images
EImageBW8 img;
EImageBW8 imgWarped;

EImageBW16 WarpX;
EImageBW16 WarpY;

// Load the image
img.Load("");

// Set size of imgWarped to what is wanted
imgWarped.SetSize(, );

// Set size of imgUnwarped to previous original image
imgUnwarped.SetSize(&img);

// Set size of warp images
WarpX.SetSize(&imgWarped);
WarpY.SetSize(&imgWarped);
EasyImage::Oper(EArithmeticLogicOperation_Copy, EBW8(0), &imgWarped);

// Do a regular ring warp
EasyImage::SetCircleWarp(, , , , , , &WarpX, &WarpY);
EasyImage::Warp(&img, &imgWarped, &WarpX, &WarpY);

```

Performing an Inverse Warping

NOTE: We use the same notation as the code snippet "Performing a Ring Warping" on page 27.

```
// Create imgUnwarped and inverseWarp images
EImageBW8 imgUnwarped;
EImageBW16 InverseWarpX;
EImageBW16 InverseWarpY;

// Set size of inverse warp images
InverseWarpX.SetSize(&img);
InverseWarpY.SetSize(&img);

EasyImage::Oper(EArithmeticLogicOperation_Copy, EBW8(0), &imgUnwarped);

EasyImage::SetInvCircleWarp( , , , , , , &InverseWarpX, &InverseWarpY);
EasyImage::Warp(&imgWarped, &imgUnwarped, &InverseWarpX, &InverseWarpY);
// Use an oper Set zero to add the background into the image
EasyImage::Oper(EArithmeticLogicOperation_SetZero, &imgUnwarped, &img, &imgUnwarped);
```

5.11. Fourier Transforms

Performing a Direct Fourier Transform

```
////////////////////////////////////
// This code snippet shows how to compute //
// the direct Fourier transform of a grayscale image //
// (from the spatial domain to the frequency domain) //
////////////////////////////////////

// Assuming you have the following loaded image
EImageBW8 spatialImage;

// Initialize an empty image that will contain frequencies information
// Be aware of the specified dimensions
EImageBW32f frequencyImage(spatialImage.GetWidth * 2, spatialImage.GetHeight);

// Compute the direct Fourier transform
EFourierTransformer fourier;
fourier.SetFrequencyDomainFormat(EFrequencyDomainFormat_ComplexExtended);
fourier.DirectTransform(spatialImage, frequencyImage);
```

Performing an Inverse Fourier Transform

```
////////////////////////////////////
// This code snippet shows how to compute //
// the inverse Fourier transform to get //
// the original grayscale image //
// (from the frequency domain to the spatial domain) //
////////////////////////////////////
```

```
// Assuming you have the following loaded image
EImageBW32f frequencyImage;

// Initialize an empty image that will contain spatial information
// Be aware of the specified dimensions
EImageBW8 spatialImage(frequencyImage.GetWidth / 2, frequencyImage.GetHeight);

// Compute the inverse Fourier transform
EFourierTransformer fourier;
fourier.SetFrequencyDomainFormat(EFrequencyDomainFormat_ComplexExtended);
fourier.InverseTransform(frequencyImage, spatialImage);
```

6. EasyColor

6.1. Colorimetric Systems Conversion

Functional Guide | Reference: [ConvertFromRgb](#), [Transform](#)

```

////////////////////////////////////
// This code snippet shows how to convert a color image //
// from the RGB to the Lab colorimetric system.         //
////////////////////////////////////

// Images constructor
EImageC24 srcImage;
EImageC24 dstImage;

// ...

// Prepare a lookup table for
// the RGB to La*b* conversion
EColorLookup lookup;
lookup.ConvertFromRgb(EColorSystem_Lab);

// Source and destination images must have the same size
dstImage.SetSize(&srcImage);

// Perform the color conversion
EasyColor::Transform(&srcImage, &dstImage, &lookup);

```

6.2. Color Components

Functional Guide | Reference: [Compose](#), [ConvertFromRgb](#), [GetComponent](#)

```

////////////////////////////////////
// This code snippet shows how to create a color image //
// from 3 grayscale images and extract the luminance    //
// component from a color image.                       //
////////////////////////////////////

// Images constructor
EImageBW8 red, green, blue;
EImageC24 colorImage;
EImageBW8 luminance;

// ...

// Source and destination images must have the same size
colorImage.SetSize(&red);

// Combine the color planes into a color image
EasyColor::Compose(&red, &green, &blue, &colorImage);

// Prepare a lookup table for

```

```
// the RGB to LSH conversion
EColorLookup lookup;
lookup.ConvertFromRgb(EColorSystem_Lsh);

// Source and destination images must have the same size
luminance.SetSize(&colorImage);

// Get the Luminance component
EasyColor::GetComponent(&colorImage, &luminance, 0, &lookup);
```

6.3. White Balance

Functional Guide | Reference: [PixelAverage](#), [WhiteBalance](#), [Transform](#)

```
////////////////////////////////////
// This code snippet shows how to perform white balancing. //
////////////////////////////////////

// Images constructor
EImageC24 srcImage, dstImage;
EImageC24 whiteRef;

// ...

// Create a lookup table
EColorLookup lut;

// Measure the calibration values from a white reference image
float r, g, b;
EasyImage::PixelAverage(&whiteRef, r, g, b);

// Prepare the lookup table for
// a white balance operation
lut.WhiteBalance(1.00f, EasyColor::GetCompensateNtscGamma(), r, g, b);

// Source and destination images must have the same size
dstImage.SetSize(&srcImage);

// Perform the white balance operation
lut.Transform(&srcImage, &dstImage);
```

6.4. Pseudo-Coloring

Functional Guide | Reference: [SetShading](#), [PseudoColor](#)

```
////////////////////////////////////
// This code snippet shows how to perform pseudo-coloring. //
////////////////////////////////////

// Images constructor
EImageBW8 srcImage;
EImageC24 dstImage;

// ...

// Create a pseudo-color lookup table
```

```
EPseudoColorLookup pcLut;

// Define a shade of pure tints, from red to blue
pcLut.SetShading(EC24(255, 0, 0), EC24(0, 0, 255), EColorSystem_Ish);

// Source and destination images must have the same size
dstImage.SetSize(&srcImage);

// Generate the pseudo-colored image
EasyColor::PseudoColor(&srcImage, &dstImage, &pcLut);
```

6.5. Bayer Pattern Decoding

Functional Guide | Reference: [BayerToC24](#)

```
////////////////////////////////////
// This code snippet shows how to perform Bayer pattern decoding. //
////////////////////////////////////

// Images constructor
EImageBW8 bayerImage;
EImageC24 dstImage;

// ...

// Source and destination images must have the same size
dstImage.SetSize(&bayerImage);

// Convert to true color with simple interpolation, default parity assumed
EasyColor::BayerToC24(&bayerImage, &dstImage);
```


7. Deep Learning Tools

7.1. Creating a Dataset and Training a Classifier

```

////////////////////////////////////
// This code snippet shows how to create a dataset, train a //
// classifier and get the best performance metrics obtained //
// during the training.                                     //
////////////////////////////////////

// Creating dataset and classifier objects
EClassificationDataset dataset;
EClassificationDataset trainingDataset;
EClassificationDataset validationDataset;
EClassifier classifier;

// Adding images using a glob pattern
dataset.AddImages("**good*.png", "good");
dataset.AddImages("**defective*.png", "defective");

// Enabling data augmentation on the dataset
dataset.SetEnableDataAugmentation(true);

// Rotation of up to 90°
dataset.SetMaxRotationAngle(90);

// Enabling horizontal flips
dataset.SetEnableHorizontalFlip(true);

// Splitting the dataset with 80% of images for the training dataset
// and 20% for the validation dataset
dataset.SplitDataset(trainingDataset, validationDataset, 0.8f);

// Training the classifier for 50 epochs
classifier.Train(trainingDataset, validationDataset, 50);
classifier.WaitForTrainingCompletion();

// Get the best metrics obtained on the validation dataset
EClassificationMetrics bestMetrics = classifier.GetValidationMetrics(classifier.GetBestEpoch());

```

7.2. Loading a Classifier and Classifying a New Image

```

////////////////////////////////////
// This code snippet shows how load a trained classifier and //
// classify a new image.                                     //
////////////////////////////////////

// Image and classifier constructor
EClassifier classifier;

```

```

EImageBW8 srcImage;

// String and probability for the most probable result
std::string label;
float probability;

// Load classifier and image
classifier.Load(...);
srcImage.Load(...);

// Classify image
EClassificationResult result = classifier.Classify(srcImage);

// Get the most probable label
label = result.GetBestLabel();
probability = result.GetBestProbability();

```

7.3. Using Multithreading for Classification

```

////////////////////////////////////
// This code snippet shows how to parallelize the //
// classification of new images on the CPU. //
// This code snippet is in C++ 11 and requires a recent //
// compiler. //
////////////////////////////////////

#include <queue>
#include <thread>
#include <mutex>
#include <atomic>
#include <condition_variable>

#define NUM_THREADS 4

class ImageQueue
{
public:
    ImageQueue() : complete_(false), maxQueueLength_(10) {}

    /// <summary>
    /// Adds an image to the queue.
    /// </summary>
    void addImage(EBaseROI* img)
    {
        {
            std::unique_lock<std::mutex> locker(mutex_);
            cv_.wait(locker, [&]() { return queue_.size() < maxQueueLength_; });
            queue_.push(img);
        }
        cv_.notify_one();
    }

    /// <summary>
    /// Takes an image from the queue. Returns a null pointer if the queue is complete and doesn't contain
    /// anymore images.
    /// </summary>
    EBaseROI* takeImage()
    {
        EBaseROI* img = nullptr;

```

```

{
    std::unique_lock<std::mutex> locker(mutex_);
    cv_.wait(locker, [&]() { return (queue_.size() > 0) || isComplete(); });

    if (queue_.size() > 0)
    {
        img = queue_.front();
        queue_.pop();
    }
}

cv_.notify_one();
return img;
}

/// <summary>
/// Indicates that the queue will not received any new images.
/// </summary>
void setComplete()
{
    complete_ = true;
}

/// <summary>
/// Checks whether the queue is empty and will not receive any new images.
/// </summary>
bool isComplete() const
{
    return queue_.size() == 0 && complete_;
}

private:
    std::atomic_bool complete_;
    std::queue<EBaseROI*> queue_;
    std::mutex mutex_;
    std::condition_variable cv_;
    int maxQueueLength_;
};

/// <summary>
/// Processing image loop.
/// </summary>
/// <param name="classifierPath">Path to the classifier used to process images</param>
/// <param name="queue">Pointer to the image queue in which to take images.</param>
void processImage(std::string segmenterPath, ImageQueue* queue)
{
    // Instanciate and load the segmenter.
    EasyDeepLearning::EClassifier classifier;
    classifier.Load(classifierPath);

    // Configure the segmenter.
    classifier.SetEnableGPU(true);
    classifier.SetBatchSize(32);

    // Loop until there are no more image to process
    while (!queue->isComplete())
    {
        // Take an image from the queue.
        EBaseROI* img = queue->takeImage();

        // If the image is null, continue the loop (and hence, check that the queue is complete).
        if (!img)
            continue;
    }
}

```

```

EasyDeepLearning::EClassificationResult r = classifier.Classify(*img);

// Perform operations based on the result.
...

// Delete the image once it is processed.
delete img;
}
}

// ...

// Create an image queue.
std::unique_ptr<ImageQueue> queue = std::make_unique<ImageQueue>();

// Declare the vector that will contain our processing threads.
std::vector<std::thread> threads;

// Create the threads
for (int i = 0; i < NUM_THREADS; i++)
{
    threads.emplace_back(processImage, "classifier.ecl", queue.get());
}

// Image acquisition loop
bool hasImage = true;
while (hasImage)
{
    EBaseROI* img;

    // Load/Create/Acquire new image
    // ...

    queue->addImage(img);
}

// Image acquisition is finished.
queue->setComplete();

// Wait for the thread to finish
for (int i = 0; i < NUM_THREADS; i++)
{
    threads[i].join();
}

```

7.4. Loading an Unsupervised Segmenter and Segmenting an Image

```

////////////////////////////////////
// This code snippet shows how to load a trained      //
// unsupervised segmenter and how to segment a new image. //
////////////////////////////////////

// Image
EImageBW8 image;
image.Load(...);

// Segmenter
EUnsupervisedSegmenter segmenter;

```

```
segmenter.Load(...);  
  
// Apply the segmenter on the image  
EUnsupervisedSegmenterResult r = segmenter.Apply(image);  
  
// Retrieve the segmentation map  
EImageBW8 segmentationMap = r.GetSegmentationMap();
```

8. EasyObject

8.1. Constructing the Blobs

Image Encoder

Functional Guide | Reference: [Encode](#), [SetBlackLayerEncoded](#), [SetWhiteLayerEncoded](#), [SetMode](#), [SetAbsoluteThreshold](#), [GetGrayscaleSingleThresholdSegmenter](#)

```

////////////////////////////////////
// This code snippet shows how to build blobs belonging to //
// the white layer according to the minimum residue method //
// and how to build blobs belonging to the black layer    //
// according to an absolute threshold.                    //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// Image encoder
EImageEncoder encoder;

// Coded image
ECodedImage2 codedImage;

// ...

// Build the blobs belonging to the white layer,
// the segmentation is based on the Minimum Residue method
encoder.Encode(srcImage, codedImage);

// Build the blobs belonging to the black layer,
// the segmentation is based on an absolute threshold (110)
Segmenters::EGrayscaleSingleThresholdSegmenter& segmenter= encoder.GetGrayscaleSingleThresholdSegmenter();
segmenter.SetBlackLayerEncoded(true);
segmenter.SetWhiteLayerEncoded(false);

segmenter.SetMode(EGrayscaleSingleThreshold_Absolute);
segmenter.SetAbsoluteThreshold(110);

encoder.Encode(srcImage, codedImage);

```

Image Segmenter

Functional Guide | Reference: [SetSegmentationMethod](#), [GetGrayscaleDoubleThresholdSegmenter](#), [SetHighThreshold](#), [SetLowThreshold](#)

```

////////////////////////////////////
// This code snippet shows how to build blobs according to //
// a user-defined image segmenter.                          //
////////////////////////////////////

```

```

////////////////////////////////////
// Image constructor
EImageBW8 srcImage;

// Image encoder
EImageEncoder encoder;

// Coded image
ECodedImage2 codedImage;

// ...

// Set the segmentation method to GrayscaleDoubleThreshold
encoder.SetSegmentationMethod(ESegmentationMethod_GrayscaleDoubleThreshold);

// Retrieve the segmenter object
Segmenters::EGrayscaleDoubleThresholdSegmenter& segmenter= encoder.GetGrayscaleDoubleThresholdSegmenter();

// Set the high and low threshold values
segmenter.SetHighThreshold(150);
segmenter.SetLowThreshold(50);

// Specify the layers to be encoded (neutral layer only)
segmenter.SetBlackLayerEncoded(false);
segmenter.SetNeutralLayerEncoded(true);
segmenter.SetWhitLayerEncoded(false);

// Encode the image
encoder.Encode(srcImage, codedImage);

```

Holes Extraction

Functional Guide | Reference: [GetHoleCount](#), [GetHole](#), [GetObjCount](#), [GetObj](#)

```

////////////////////////////////////
// This code snippet shows how to retrieve blobs' holes. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// Image encoder
EImageEncoder encoder;

// Coded image
ECodedImage2 codedImage;

// ...

// Encode the image
encoder.Encode(srcImage, codedImage);

// Retrieve holes for all the blobs
for (unsigned int blobIndex = 0; blobIndex < codedImage.GetObjCount(); blobIndex++)
{
    EObject& blob = codedImage.GetObj(blobIndex);

    // Browse the holes of the current object
    for (unsigned int holeIndex = 0; holeIndex < blob.GetHoleCount(); holeIndex++)
    {

```

```

        // Retrieve a given hole
        EHole& hole = blob.GetHole(holeIndex);
    }
}

```

Continuous Mode

Functional Guide | Reference: [SetContinuousModeEnabled](#), [FlushContinuousMode](#)

```

////////////////////////////////////
// This code snippet shows how to build blobs //
// in the continuous mode context. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// Image encoder
EImageEncoder encoder;

// Coded image
ECodedImage2 codedImage;

// ...

// Enable the continuous mode
encoder.SetContinuousModeEnabled(true);

// Loop to acquire the different chunks
for (int count = 0; count < MAX_COUNT ; count++)
{
    // Store the new chunk into srcImage
    // ...

    // Encode the current chunk
    encoder.Encode(srcImage, codedImage);
}

// Flush the continuous mode
encoder.FlushContinuousMode(codedImage);

```

8.2. Computing Blobs Features

Functional Guide | Reference: [GetGravityCenter](#), [GetObj](#)

```

////////////////////////////////////
// This code snippet shows how to retrieve blobs' features. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// Image encoder
EImageEncoder encoder;

// Coded image
ECodedImage2 codedImage;

```



```
// ...

// Encode the source image
encoder.Encode(srcImage, codedImage);

for (unsigned int index = 0; index < codedImage.GetObjCount(); index++)
{
    // Retrieve the selected blob gravity center
    EObject& blob = codedImage.GetObj(index);
    float centerX = blob.GetGravityCenter().GetX();
    float centerY = blob.GetGravityCenter().GetY();
}
}
```

8.3. Selecting and Sorting Blobs

Functional Guide | Reference: [AddObjects](#), [ElementCount](#), [RemoveUsingUnsignedIntegerFeature](#), [Sort](#)

```
////////////////////////////////////
// This code snippet shows how to build blobs, select //
// some of them and sort the selected ones.         //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// Image encoder
EImageEncoder encoder;

// Coded image
ECodedImage2 codedImage;

// ...

// Encode the source image
encoder.Encode(srcImage, codedImage);

// Create a blob selection
EObjectSelection selection;
selection.AddObjects(codedImage);

// Remove the Small blobs
selection.RemoveUsingUnsignedIntegerFeature(EFeature_Area, 100, ESingleThresholdMode_Less);

// Retrieve the number of remaining blobs
unsigned int numBlobs= selection.GetElementCount();

// Sort the remaining blobs based on their area
selection.Sort(EFeature_Area, ESortDirection_Ascending);

// Retrieve the selected blobs
for (unsigned int index = 0; index < numBlobs; index++)
{
    float centerX= selection.GetElement(index).GetGravityCenterX();
    float centerY= selection.GetElement(index).GetGravityCenterY();
}
}
```

8.4. Using Flexible Masks

Constructing Blobs

Functional Guide | Reference: [Encode](#)

```

////////////////////////////////////
// This code snippet shows how to build blobs inside //
// a region defined by a flexible mask.             //
////////////////////////////////////

// Images constructor
EImageBW8 srcImage;
EImageBW8 mask;

// Image encoder
EImageEncoder encoder;

// Coded image
ECodedImage2 codedImage;

// ...

// Encode the source image regions
// corresponding to the mask do care areas
encoder.Encode(srcImage, mask, codedImage);

```

Generating a Flexible Mask from an Encoded Image

Functional Guide | Reference: [RenderMask](#)

```

////////////////////////////////////
// This code snippet shows how to generate a flexible //
// mask from an encoded image.                       //
////////////////////////////////////

// Images constructor
EImageBW8 srcImage;
EImageBW8 mask;

// Image encoder
EImageEncoder encoder;

// Coded image
ECodedImage2 codedImage;

// ...

// Encode the source image
encoder.Encode(srcImage, codedImage);

// The source image and the mask must have the same size
mask.SetSize(&srcImage);

// Create the mask based on the white layer
// of the coded image

```

```
codedImage.RenderMask(mask, 1);
```

Generating a Flexible Mask from a Blob Selection

Functional Guide | Reference: [RenderMask](#)

```

////////////////////////////////////
// This code snippet shows how to generate a flexible //
// mask from a selection of blobs.                    //
////////////////////////////////////

// Images constructor
EImageBW8 srcImage;
EImageBW8 mask;

// Image encoder
EImageEncoder encoder;

// Coded image
ECodedImage2 codedImage;

// ...

// Encode the source image
encoder.Encode(srcImage, codedImage);

// The source image and the mask must have the same size
mask.SetSize(&srcImage);

// Create a blob selection
EObjectSelection selection;
selection.AddObjects(codedImage);

// Remove the Small blobs
selection.RemoveUsingUnsignedIntegerFeature(EFeature_Area, 100, ESingleThresholdMode_Less);

// Create the mask based on the blob selection
selection.RenderMask(mask);

// Sort the remaining blobs based on their area
selection.Sort(EFeature_Area, ESortDirection_Descending);

// Create the mask corresponding to the largest blob
selection.GetElement(0).RenderMask(mask);

```

8.5. Using the Object Template Matcher

Functional Guide | Reference: [EObjectTemplateMatcher](#)

```

////////////////////////////////////
// This code snippet shows how to use EObjectTemplateMatcher//
// for alignment and template matching                //
////////////////////////////////////

// Encode the template image
EImageEncoder encoder;
ECodedImage2 coded_img;

```

```
EImageBW8 template_img;
encoder.Encode(template_img, coded_img);

// Initialize EObjectTemplateMatcher
EObjectTemplateMatcher object_matcher;
object_matcher.SetEnableAlignment(true); // optional
object_matcher.SetMaximumDistance(60); // optional

// set the template
object_matcher.BuildTemplate(coded_img);

// Encode the test image
EImageBW8 test_img;
encoder.Encode(test_img, coded_img);

// Build a selection of test objects
EObjectSelection object_select;
object_select.AddObjects(coded_img);
object_select.RemoveUsingUnsignedIntegerFeature(EFeature_Area, 10, ESingleThresholdMode_Less); // optional
filter

// Perform the alignment and the matching
object_matcher.SortSelection(object_select);

// Display the number of matches
std::cout << object_matcher.GetNumberOfPairedObjects() << " paired objects" << std::endl;

// Retrieve the template indexes for each selection object
std::vector<int> template_indexes = object_matcher.GetTemplateIndexes();
```

9. EasyMatch

9.1. Pattern Learning

Functional Guide | Reference: [LearnPattern](#)

```
////////////////////////////////////  
// This code snippet shows how to learn a pattern //  
// defined by a region of interest (ROI).      //  
////////////////////////////////////  
  
// Image constructor  
EImageBW8 srcImage;  
  
// ROI constructor  
EROIBW8 pattern;  
  
// EMatcher constructor  
EMatcher matcher;  
  
// ...  
  
// Attach the ROI to the source image  
// and set its position  
pattern.Attach(&srcImage);  
pattern.SetPlacement(214, 52, 200, 200);  
  
// Learn the pattern  
matcher.LearnPattern(&pattern);
```

9.2. Setting Search Parameters

Functional Guide | Reference: [SetMaxPositions](#), [SetMinAngle](#), [SetMaxAngle](#), [SetMinScore](#), [SetInterpolate](#), [Save](#)

```
////////////////////////////////////  
// This code snippet shows how to tune pattern matching //  
// search parameters and save them into a file.      //  
////////////////////////////////////  
  
// Image constructor  
EImageBW8 pattern;  
  
// EMatcher constructor  
EMatcher matcher;  
  
// ...  
  
// Learn the pattern  
matcher.LearnPattern(&pattern);  
  
// Set the maximum number of occurrences
```

```

matcher.SetMaxPositions(5);

// Set the rotation tolerances
matcher.SetMinAngle(-20.f);
matcher.SetMaxScale(20.f);

// Enable sub-pixel accuracy
matcher.SetInterpolate(true);

// Set the minimum score
matcher.SetMinScore(0.70f);

// Save the matching context into a model file
matcher.Save("myModel.mch");

```

9.3. Pattern Matching and Retrieving Results

Functional Guide | Reference: [Load](#), [Match](#), [GetNumPositions](#), [GetPosition](#)

```

////////////////////////////////////
// This code snippet shows how to perform pattern //
// matching operations and retrieve the results. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// EMatcher constructor
EMatcher matcher;

// ...

// Load a model file
matcher.Load("myModel.mch");

// Perform the matching
matcher.Match(&srcImage);

// Retrieve the number of occurrences
int numOccurrences= matcher.GetNumPositions();

// Retrieve the first occurrence
EMatchPosition myOccurrence= matcher.GetPosition(0);

// Retrieve its score and position
float score= myOccurrence.Score;
float centerX= myOccurrence.CenterX;
float centerY= myOccurrence.CenterY;

```

9.4. Pattern Learning with ERegion

Functional Guide | Reference: [LearnPattern](#)

```

////////////////////////////////////
// This code snippet shows how to learn a pattern //
// whose region of interest is defined by an ERegion //

```

```
////////////////////////////////////  
EImageBW8 srcImage;  
EROIBW8 pattern;  
EMatcher matcher;  
// ...  
// Attach the ROI to the source image and set its position  
pattern.Attach(&srcImage);  
pattern.SetPlacement(214, 52, 200, 200);  
  
// pattern is a 200*200 square but here we are only  
// interested in the inner circle  
  
// OLD method (warning, advanced learning is not compatible with this)  
matcher.SetDontCareThreshold(1);  
// must paint the part of pattern we are not interested in in black  
matcher.LearnPattern(&pattern);  
  
// NEW method (compatible with advanced learning)  
ECircleRegion region(100.f, 100.f, 100.f);  
matcher.LearnPattern(&pattern, region);
```

10. EasyFind

10.1. Pattern Learning

Functional Guide | Reference: [Learn](#)

```
////////////////////////////////////  
// This code snippet shows how to learn a pattern //  
// defined by a region of interest (ROI).      //  
////////////////////////////////////  
  
// Image constructor  
EImageBW8 srcImage;  
  
// ROI constructor  
EROIBW8 pattern;  
  
// EPatternFinder constructor  
EPatternFinder finder;  
  
// ...  
  
// Attach the ROI to the source image  
// and set its position  
pattern.Attach(&srcImage);  
pattern.SetPlacement(214, 52, 200, 200);  
  
// Learn the pattern  
finder.Learn(&pattern);
```

10.2. Setting Search Parameters

Functional Guide | Reference: [SetMaxInstances](#), [SetAngleTolerance](#), [SetMinScore](#), [Save](#)

```
////////////////////////////////////  
// This code snippet shows how to tune pattern finding //  
// search parameters and save them into a file.      //  
////////////////////////////////////  
  
// Image constructor  
EImageBW8 pattern;  
  
// EPatternFinder constructor  
EPatternFinder finder;  
  
// ...  
  
// Learn the pattern  
finder.Learn(&pattern);  
  
// Set the maximum number of occurrences  
finder.SetMaxInstances(5);
```



```
// Set the rotation tolerances
finder.SetAngleTolerance(20.f);

// Set the minimum score
finder.SetMinScore(0.70f);

// Save the finding context into a model file
finder.Save("myModel.fnd");
```

10.3. Pattern Finding and Retrieving Results

Functional Guide | Reference: [Load](#), [Find](#), [GetScore](#), [GetCenter](#)

```
////////////////////////////////////
// This code snippet shows how to perform pattern //
// finding operations and retrieve the results. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// EPatternFinder constructor
EPatternFinder finder;

// EFoundPattern constructor
std::vector<EFoundPattern> foundPattern;

// ...

// Load a model file
finder.Load("myModel.fnd");

// Perform the pattern finding
foundPattern= finder.Find(&srcImage);

// Retrieve the number of instances
int numInstances= (int)foundPattern.size();

// Retrieve the score and the
// position of the first instance
float score= foundPattern[0].GetScore();
float centerX= foundPattern[0].GetCenter().GetX();
float centerY= foundPattern[0].GetCenter().GetY();
```

10.4. Learning Using a DXF File

Functional Guide | Reference: [LoadDXF](#), [Find](#)

```
////////////////////////////////////
// This code snippet shows how to perform //
// pattern learning and finding operations //
// using a DXF file. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;
```

```
// EPatternFinder constructor
EPatternFinder finder;
// EVectorModel constructor
EVectorModel myModel;
// Load the model from a dxf file
myModel.LoadDXF("myModel.dxf");
// Learn the model
finder.Learn(myModel);
// EFoundPattern constructor
std::vector<EFoundPattern> foundPattern;
// ...
// Perform the pattern finding
foundPattern = finder.Find(&srcImage);
```

10.5. Learning Using an EPolygonShape

Functional Guide | Reference: [SetPolygon](#), [Find](#)

```
////////////////////////////////////
// This code snippet shows how to perform //
// pattern learning and finding operations //
// using EPolygonShape to define the model. //
////////////////////////////////////
// Image constructor
EImageBW8 srcImage;
// EPatternFinder constructor
EPatternFinder finder;
// EVectorModel constructor
EVectorModel myModel;
// Get the root EFrameShape of the model
EFrameShape& shapeMother = myModel.GetRoot();
// EPolygonShape constructor
EPolygonShape polygon;
// Define the vertices of a polygon
std::vector<EPoint> vertices = { {0.f, 0.f}, {1.f, 0.f}, {1.f, 1.f}, {0.f, 1.f} };
// Define the EPolygonShape
polygon.SetPolygon(EPolygon(vertices, true));
// Attach the EPolygonShape to the root EFrameShape
polygon.Attach(&shapeMother);
// Sets the polarity of the EPolygonShape
polygon.SetProperty("polarity", "direct");
// Learn the model
finder.Learn(myModel);
// EFoundPattern constructor
std::vector<EFoundPattern> foundPattern;
// ...
// Perform the pattern finding
foundPattern = finder.Find(&srcImage);
```

11. EasyGauge

11.1. Point Location

Functional Guide | Reference: [SetTransitionType](#), [SetTransitionChoice](#), [SetCenterXY](#), [SetTolerance](#), [Measure](#), [GetMeasuredPoint](#), [GetX](#), [GetY](#)

```

////////////////////////////////////
// This code snippet shows how to create a point location tool, //
// adjust the transition parameters, set the nominal gauge      //
// position, perform the measurement and retrieve the result.   //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// EPointGauge constructor
EPointGauge pointGauge;

// Adjust the transition parameters
pointGauge.SetTransitionType(ETransitionType_Wb);
pointGauge.SetTransitionChoice(ETransitionChoice_Closest);

// Set the gauge nominal position
pointGauge.SetCenterXY(256.f, 256.f);

// Set the gauge length to 100 units and the angle to 45°
pointGauge.SetTolerances(100.f, 45.f);

// Measure
pointGauge.Measure(&srcImage);

// Get the measured point coordinates
float measuredX = pointGauge.GetMeasuredPoint().GetX();
float measuredY = pointGauge.GetMeasuredPoint().GetY();

// Save the point gauge measurement context
pointGauge.Save("myPointGauge.gge");

```

11.2. Line Fitting

Functional Guide | Reference: [SetTransitionType](#), [SetTransitionChoice](#), [SetTransitionIndex](#), [SetLine](#), [Measure](#), [GetMeasuredLine](#), [GetOrg](#), [GetEnd](#)

```

////////////////////////////////////
// This code snippet shows how to create a line measurement tool, //
// adjust the transition parameters, set the nominal gauge      //
// position, perform the measurement and retrieve the result.   //
////////////////////////////////////

// Image constructor

```

```

EImageBW8 srcImage;

// ELineGauge constructor
ELineGauge lineGauge;

// Adjust the transition parameters
lineGauge.SetTransitionType(ETransitionType_Bw);
lineGauge.SetTransitionChoice(ETransitionChoice_NthFromEnd);
lineGauge.SetTransitionIndex(2);

// Set the line fitting gauge position,
// length (50 units) and orientation (20°)
EPoint center(256.f, 256.f);
ELine line(center, 50.f, 20.f);
lineGauge.SetLine(line);

// Measure
lineGauge.Measure(&srcImage);

// Get the origin and end point coordinates of the fitted line
EPoint originPoint = lineGauge.GetMeasuredLine().GetOrg();
EPoint endPoint = lineGauge.GetMeasuredLine().GetEnd();

// Save the point gauge measurement context
lineGauge.Save("myLineGauge.gge");

```

11.3. Circle Fitting

Functional Guide | Reference: [SetTransitionType](#), [SetTransitionChoice](#), [SetCircle](#), [Measure](#), [GetMeasuredCircle](#), [GetCenter](#), [GetRadius](#)

```

////////////////////////////////////
// This code snippet shows how to create a circle measurement tool, //
// adjust the transition parameters, set the nominal gauge          //
// position, perform the measurement and retrieve the result.      //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// ECircleGauge constructor
ECircleGauge circleGauge;

// Adjust the transition parameters
circleGauge.SetTransitionType(ETransitionType_Bw);
circleGauge.SetTransitionChoice(ETransitionChoice_LargestAmplitude);

// Set the Circle fitting gauge position, diameter (50 units),
// starting angle (10°), and amplitude (270°)
EPoint center(256.f, 256.f);
ECircle circle(center, 50.f, 10.f, 270.f);
circleGauge.SetCircle(circle);

// Measure
circleGauge.Measure(&srcImage);

// Get the center point coordinates and the radius of the fitted circle
float centerX = circleGauge.GetMeasuredCircle().GetCenter().GetX();
float centerY = circleGauge.GetMeasuredCircle().GetCenter().GetY();
float radius = circleGauge.GetMeasuredCircle().GetRadius();

```

```
// Save the point gauge measurement context
circleGauge.Save("myCircleGauge.gge");
```

11.4. Rectangle Fitting

Functional Guide | Reference: [SetTransitionType](#), [SetTransitionChoice](#), [SetRectangle](#), [Measure](#), [GetMeasuredRectangle](#), [GetSizeX](#), [GetSizeY](#), [GetAngle](#)

```
////////////////////////////////////
// This code snippet shows how to create a rectangle measurement tool, //
// adjust the transition parameters, set the nominal gauge position, //
// perform the measurement and retrieve the result. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// ERectangleGauge constructor
ERectangleGauge rectangleGauge;

// Adjust the transition parameters
rectangleGauge.SetTransitionType(ETransitionType_Bw);
rectangleGauge.SetTransitionChoice(ETransitionChoice_LargestAmplitude);

// Set the rectangle fitting gauge position,
// size (50x30 units) and orientation (15°)
EPoint center(256.f, 256.f);
ERectangle rectangle(center, 50.f, 30.f, 15.f);
rectangleGauge.SetRectangle(rectangle);

// Measure
rectangleGauge.Measure(&srcImage);

// Get the size and the rotation angle of the fitted rectangle
float sizeX = rectangleGauge.GetMeasuredRectangle().GetSizeX();
float sizeY = rectangleGauge.GetMeasuredRectangle().GetSizeY();
float angle = rectangleGauge.GetMeasuredRectangle().GetAngle();

// Save the point gauge measurement context
rectangleGauge.Save("myRectangleGauge.gge");
```

11.5. Wedge Fitting

Functional Guide | Reference: [SetTransitionType](#), [SetTransitionChoice](#), [SetWedge](#), [Measure](#), [GetMeasuredWedge](#), [GetInnerRadius](#), [GetOuterRadius](#)

```
////////////////////////////////////
// This code snippet shows how to create a wedge measurement tool, //
// adjust the transition parameters, set the nominal gauge //
// position, perform the measurement and retrieve the result. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;
```

```
// EWedgeGauge constructor
EWedgeGauge wedgeGauge;

// Adjust the transition parameters
wedgeGauge.SetTransitionType(ETransitionType_Bw);
wedgeGauge.SetTransitionChoice(ETransitionChoice_NthFromBegin);
wedgeGauge.SetTransitionIndex(0);

// Set the wedge fitting gauge position, diameter (50 units),
// breadth (-25 units), starting angle (0°) and amplitude (270°)
EPoint center(256.f, 256.f);
EWedge wedge(center, 50.f, -25.f, 0.f, 270.f);
wedgeGauge.SetWedge(wedge);

// Measure
wedgeGauge.Measure(&srcImage);

// Get the inner and outer radius of the fitted wedge
float innerRadius = wedgeGauge.GetMeasuredWedge().GetInnerRadius();
float outerRadius = wedgeGauge.GetMeasuredWedge().GetOuterRadius();

// Save the point gauge measurement context
wedgeGauge.Save("myWedgeGauge.gge");
```

11.6. Gauge Grouping

Gauge Hierarchy

Functional Guide | Reference: [Attach](#), [SetName](#), [Save](#)

```
////////////////////////////////////
// This code snippet shows how to create a gauge hierarchy //
// and save it into a file. //
////////////////////////////////////

// EWorldShape constructor
EWorldShape worldShape;

// Gauges constructor
ERectangleGauge rectangleGauge;
ECircleGauge circleGauge1, circleGauge2;

// ...

// Attach the rectangle gauge to the EWorldShape
rectangleGauge.Attach(&worldShape);

// Attach the circle gauges to the rectangle gauge
circleGauge1.Attach(&rectangleGauge);
circleGauge2.Attach(&rectangleGauge);

// Set the first circle gauge name
circleGauge1.SetName("myCircleGauge1");

// ...

// Save worldShape together with its daughters
worldShape.Save("myWorldShape.gge", true);
```

Complex Measurement

Functional Guide | Reference: [Load](#), [GetNumDaughters](#), [Process](#), [GetDaughter](#), [GetShapeNamed](#)

```

////////////////////////////////////
// This code snippet shows how to trigger the measurement //
// of a whole gauge hierarchy and retrieve the results. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// EWorldShape constructor
EWorldShape worldShape;

// Load the EWorldShape together with its daughters
worldShape.Load("myWorldShape.gge", true);

// Retrieve the number of worldShape's daughters
int numDaughters= worldShape.GetNumDaughters();

// ...

// Trigger the measurement of all the
// gauges attached to the EWorldShape
worldShape.Process(&srcImage, true);

// Retrieve the measurement result of
// the first daughter (a rectangle gauge)
ERectangleGauge* rectangleGauge= (ERectangleGauge*)worldShape.GetDaughter(0);
float sizeX= rectangleGauge->GetMeasuredRectangle().GetSizeX();

// Retrieve the measurement result of a
// daughter gauge called "myCircleGauge1"
ECircleGauge* circleGauge= (ECircleGauge*)worldShape.GetShapeNamed("myCircleGauge1");
EPoint center= circleGauge->GetMeasuredCircle().GetCenter();

```

11.7. Calibration using EWorldShape

Functional Guide | [Reference](#)

Calibration by Guesswork

Functional Guide | Reference: [SetSensor](#), [GetXResolution](#), [GetYResolution](#)

```

////////////////////////////////////
// This code snippet shows how to perform a calibration //
// by guesswork. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// EWorldShape constructor
EWorldShape worldShape;

```

```
// ...

// Compute the calibration coefficients
// Field of view: 32x24 mm
worldShape.SetSensor(srcImage.GetWidth(), srcImage.GetHeight(), 32.f, 24.f);

// Retrieve the spatial resolution
float resolutionX= worldShape.GetXResolution();
float resolutionY= worldShape.GetYResolution();
```

Landmark-Based Calibration

Functional Guide | Reference: [EmptyLandmarks](#), [AddLandmark](#), [Calibrate](#)

```
////////////////////////////////////
// This code snippet shows how to perform a landmark-based //
// calibration.                                           //
////////////////////////////////////

// EWorldShape constructor
EWorldShape worldShape;

// ...

// Reset the calibration context
worldShape.EmptyLandmarks();

// Loop on the landmarks
for(int index= 0; index < numLandmarks; index++)
{
    // Get the I-th landmark as a pair of EPoint(x, y)
    EPoint sensorPoint, worldPoint;

    // Retrieve and store the relevant data into worldPoint and sensorPoint
    // ...

    // Add the I-th pair
    worldShape.AddLandmark(sensorPoint, worldPoint);
}

// Perform the calibration
worldShape.Calibrate(ECalibrationMode_Skewed);
```

Dot Grid-Based Calibration

Functional Guide | Reference: [EmptyLandmarks](#), [AddPoint](#), [RebuildGrid](#), [AutoCalibrate](#)

```
////////////////////////////////////
// This code snippet shows how to perform a dot grid-based //
// calibration.                                           //
////////////////////////////////////

// EWorldShape constructor
EWorldShape worldShape;

// ...
```



```
// Reset the calibration context
worldShape.EmptyLandmarks();

// Loop on the dots
for(int index= 0; index < numDots; index++)
{
    // Get the I-th dot as an EPoint(x, y)
    EPoint dotPoint;

    // Retrieve and store the relevant data into dotPoint
    // ...

    // Add the I-th dot
    worldShape.AddPoint(dotPoint);
}

// Reconstruct the grid topology
// pitch X and Y = 5 units
worldShape.RebuildGrid(5, 5);

// Perform the calibration
// the calibration modes are computed automatically
worldShape.AutoCalibrate(true);
```

Coordinates Transform

Functional Guide | Reference: [SensorToWorld](#), [WorldToSensor](#)

```
////////////////////////////////////
// This code snippet shows how to convert coordinates from //
// the Sensor space to the World space and conversely. //
////////////////////////////////////

// EWorldShape constructor
EWorldShape worldShape;

// EPoint constructor
EPoint sensor;
EPoint world;

// ...

// Perform the calibration
worldShape.Calibrate(ECalibrationMode_Scaled | ECalibrationMode_Skewed);

// Retrieve the world coordinates of a point, knowing its sensor coordinates
world= worldShape.SensorToWorld(sensor);

// Retrieve the sensor coordinates of a point, knowing its world coordinates
sensor= worldShape.WorldToSensor(world);
```

Image Unwarping

Functional Guide | Reference: [SetupUnwarp](#), [Unwarp](#)

```
////////////////////////////////////
// This code snippet shows how to unwarp an image based //
// of the computed calibration coefficients. //
```

```
////////////////////////////////////  
// Images constructor  
EImageBW8 srcImage;  
EImageBW8 dstImage;  
  
// EWorldShape constructor  
EWorldShape worldShape;  
  
// Lookup table constructor  
EUnwarpingLut lut;  
  
// ...  
  
// Perform the calibration  
worldShape.Calibrate(ECalibrationMode_Tilted | ECalibrationMode_Radial);  
  
// Setup the lookup table for unwarping  
worldShape.SetupUnwarp(&lut, &srcImage, true);  
  
// Perform the image unwarping  
worldShape.Unwarp(&lut, &srcImage, &dstImage, true);
```

12. EasyOCR

12.1. Learning Characters

Functional Guide | Reference: [NewFont](#), [SetTextColor](#), [SetMinCharWidth](#), [SetMaxCharWidth](#), [SetMinCharHeight](#), [SetMaxCharHeight](#), [SetNoiseArea](#), [LearnPatterns](#), [BuildObjects](#), [FindAllChars](#), [Save](#)

```
////////////////////////////////////  
// This code snippet shows how to learn characters //  
// based on an image featuring a known text and //  
// save the corresponding font file. //  
////////////////////////////////////  
  
// Image constructor  
EImageBW8 srcImage;  
  
// EOCR constructor  
EOCR ocr;  
  
// Text to be learned (all digits)  
// Assuming the image contains this text  
const std::string text= "0123456789";  
  
// ...  
  
// Create a new font  
ocr.NewFont(8, 11);  
  
// Adjust the segmentation parameters  
ocr.SetTextColor(EOCRColor_BlackOnWhite);  
ocr.SetMinCharWidth(15);  
ocr.SetMinCharWidth(50);  
ocr.SetMinCharHeight(15);  
ocr.SetMinCharHeight(75);  
ocr.SetNoiseArea(15);  
  
// Segment the characters  
ocr.BuildObjects(&srcImage);  
ocr.FindAllChars(&srcImage);  
  
// Learn the characters  
ocr.LearnPatterns(&srcImage, text, EOCClass_Digit);  
  
// Save the font into a file  
ocr.Save("myFont.ocr");
```

12.2. Recognizing Characters

Functional Guide | Reference: [Load](#), [Recognize](#)

```
////////////////////////////////////
// This code snippet shows how to load a font file, //
// perform a default character recognition operation //
// and perform a character recognition operation    //
// using a class filter.                            //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// EOCR constructor
EOCR ocr;

// Load the font file
ocr.Load("myFont.ocr");

// ...

// Recognize the characters
std::string text= ocr.Recognize(&srcImage, 10, EOCCClass_AllClasses);

// Alternatively
// Define the character filter (2 letters and 3 digits)
std::vector<UINT32> charFilter;
charFilter.push_back(EOCCClass_UpperCase);
charFilter.push_back(EOCCClass_UpperCase);
charFilter.push_back(EOCCClass_Digit);
charFilter.push_back(EOCCClass_Digit);
charFilter.push_back(EOCCClass_Digit);

// Recognize the characters with class filtering
text= ocr.Recognize(&srcImage, 10, charFilter);
```


13. EasyOCR2

13.1. Detecting Characters

```

////////////////////////////////////
// This code snippet shows how to detect characters //
// in an image, using a few parameters and a topology //
////////////////////////////////////
// Load an Image
EImageBW8 image;
image.Load("image.tif");
// Attach a ROI to the image
EROIBW8 roi;
roi.Attach(&image, 50, 224, 340, 96);
// Create an EOCR2 instance
EOCR2 ocr2;
// Set the expected character sizes
ocr2.SetCharsWidthRange(EIntegerRange(25,25));
ocr2.SetCharsHeight(37);
// Set the text polarity, in this case WhiteOnBlack
ocr2.SetTextPolarity(EasyOCR2TextPolarity_WhiteOnBlack);
// Set the topology
ocr2.SetTopology(".{10}\n.{3} .{4}");
// Detect the text in the image. The output Text structure contains:
// - an individual textbox for each character
// - an individual bitmap image for each character
// - a threshold value to binarize the bitmap image for each character
// All structured in a hierarchy with Lines -> Words -> Characters
EOCR2Text text = ocr2.Detect(roi);

```



The image used in this code snippet

13.2. Learning Characters

```

////////////////////////////////////
// This code snippet shows how to learn characters //
// based on an image featuring a known text and //
// save the corresponding character database //
////////////////////////////////////
// Load an Image

```

```

EImageBW8 image;
image.Load("image.tif");
// Attach a ROI to the image
EROIBW8 roi;
roi.Attach(&image, 50, 224, 340, 96);

// Create an EOOCR2 instance
EOOCR2 ocr2;


// Set the required parameters
ocr2.SetCharsWidthRange(EIntegerRange(25,25));
ocr2.SetCharsHeight(37);
ocr2.SetTextPolarity(EasyOCR2TextPolarity_WhiteOnBlack);
ocr2.SetTopology(".{10}\\n.{3} .{4}");

// Learn from the reference image:
// 1) Detect the text in the image
EOOCR2Text text = ocr2.Detect(roi);
// 2) Set the true values of the text
text.SetText("Bt121KPJ80\n786 9512");
// 3) Add the characters to the character database
ocr2.Learn(text);

// Save the character database
ocr2.SaveCharacterDatabase("myDB.o2d");

// Alternatively, save the model file.
// This will store the character database and the parameter settings
ocr2.Save("myModel.o2m");

```



The image used in this code snippet

13.3. Reading Characters

Reading Using TrueType Fonts

```

////////////////////////////////////
// This code snippet shows how to //
// - create a character database from TrueType fonts //
// - read the text in an image //
////////////////////////////////////

// Load an image
EImageBW8 image;
image.Load("image.tif");

```

```
// Attach an ROI
EROIBW8 roi;
roi.Attach(&image, 50, 224, 340, 96);

// Create an EOCR2 instance
EOCR2 ocr2;

// Set the required parameters
ocr2.SetCharsWidthRange(EIntegerRange(25,25));
ocr2.SetCharsHeight(37);
ocr2.SetTopology("[LN]{10}\nN{3} N{4}");
ocr2.SetTextPolarity(EasyOCR2TextPolarity_WhiteOnBlack);

// Add TrueType character to the character database
ocr2.AddCharactersToDatabase("C:\\Windows\\Fonts\\calibri.ttf");
ocr2.AddCharactersToDatabase("C:\\Windows\\Fonts\\yugothb.ttf");

// Read text from the image
std::string result = ocr2.Read(roi);
```



The image used in this code snippet

Reading Using EOCR2 Character Database

```
////////////////////////////////////
// This code snippet shows how to //
// - load a pre-made character database //
// - read the text in an image //
////////////////////////////////////

// Load an image
EImageBW8 image;
image.Load("image.tif");

// Attach an ROI
EROIBW8 roi;
roi.Attach(&image, 50, 224, 340, 96);

// Create an EOCR2 instance
EOCR2 ocr2;

// Set the required parameters
ocr2.SetCharsWidthRange(EIntegerRange(25,25));
ocr2.SetCharsHeight(37);
ocr2.SetTopology("[LN]{10}\nN{3} N{4}");
ocr2.SetTextPolarity(EasyOCR2TextPolarity_WhiteOnBlack);

// Add a pre-made character database to the EOCR2 instance
ocr2.AddCharactersToDatabase("myDB.o2d");
```

```
// Read text from the image
std::string result = ocr2.Read(roi);
```

Reading Using EOCR2 Model File

```
////////////////////////////////////
// This code snippet shows how to //
// - load a pre-made model file //
// - read the text in an image //
////////////////////////////////////

// Load an image
EImageBW8 image;
image.Load("image.tif");

// Attach an ROI
EROIBW8 roi;
roi.Attach(&image, 50, 224, 340, 96);

// Create an EOCR2 instance
EOCR2 ocr2;

// Load a pre-made model file, this will:
// - (re)set all parameters
// - add the character database in the model file to the EOCR2 instance
ocr2.Load("myModel.o2m");

// Read text from the image
std::string result = ocr2.Read(roi);
```

13.4. View Bitmap

```
////////////////////////////////////
// This code snippet shows how to inspect the //
// characters in a character database //
////////////////////////////////////
// Create an EOCR2 instance
EOCR2 ocr2;

// Load the character database
ocr2.AddCharactersToDatabase("database.o2d");
// Extract the character database
EOCR2CharacterDatabase db = ocr2.GetCharacterDatabase();

// Select the character that we are interested in (e.g. the third one)
EOCR2DatabaseCharacter chr = db.GetCharacter(2);
// Extract the bitmap for that character
EImageBW8 img = chr.GetBitmap();
```


14. EasyBarCode

14.1. Reading a Bar Code

Functional Guide | Reference: [Read](#)

```
////////////////////////////////////  
// This code snippet shows how to read a bar code //  
////////////////////////////////////  
  
// Image constructor  
EImageBW8 srcImage;  
  
// Bar code reader constructor  
EBarCode reader;  
  
// String for the decoded bar code  
std::string result;  
  
// ...  
  
// Read the source image  
result = reader.Read(&srcImage);
```

14.2. Reading a Bar Code Following a Given Symbology

Functional Guide | Reference: [SetAdditionalSymbologies](#), [Detect](#), [Decode](#)

```
////////////////////////////////////  
// This code snippet shows how to enable a given symbology, //  
// enable the checksum verification, perform the bar code //  
// detection and retrieve the decoded string. //  
////////////////////////////////////  
  
// Image constructor  
EImageBW8 srcImage;  
  
// Bar code reader constructor  
EBarCode reader;  
  
// String for the decoded bar code  
std::string result;  
  
// ...  
  
// Disable all standard symbologies  
reader.SetStandardSymbologies(0);  
  
// Enable the Code32 symbology only
```

```

reader.SetAdditionalSymbologies(ESymbologies_Code32);

// Enable checksum verification
reader.SetVerifyChecksum(true);

// Detect all possible meanings of the bar code
reader.Detect(&srcImage);

// Retrieve the number of symbologies for
// which the decoding process was successful
int numDecoded = reader.GetNumDecodedSymbologies();

if(numDecoded > 0)
{
    // Decode the bar code according to the Code32 symbology
    result = reader.Decode(ESymbologies_Code32);
}

```

14.3. Reading a Bar Code of Known Location

Functional Guide | Reference: [SetCenterXY](#), [SetReadingSize](#)

```

////////////////////////////////////
// This code snippet shows how to specify the bar code //
// position and perform the bar code reading.          //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// Bar code reader constructor
EBarCode reader;

// String for the decoded bar code
std::string result;

// ...

// Disable automatic bar code detection
reader.SetKnownLocation(TRUE);

// Set the bar code position
reader.SetCenterXY(450.0f, 400.0f);
reader.SetSize(250.0f, 110.0f);
reader.SetReadingSize(1.15f, 0.5f);

// Read the bar code at the specified location
result = reader.Read(&srcImage);

```

14.4. Reading a Mail Bar Code

Functional Guide | Reference: [Read](#)

```

////////////////////////////////////
// This code snippet shows how to read Mail Barcodes //
// and retrieve the decoded data.                      //

```

```
////////////////////////////////////  
  
// Image constructor  
EImageBW8 srcImage;  
// Mail bar code reader constructor  
EMailBarcodeReader reader;  
  
// Select expected symbologies and orientations (optional)  
reader.SetExpectedSymbologies(...);  
reader.SetExpectedOrientations(...);  
// ...  
// Read  
std::vector<EMailBarcode> codes = reader.Read(srcImage);  
// Retrieve the data included in found mail barcodes  
for (unsigned int index= 0; index < codes.size(); index++)  
{  
    std::string text = codes[index].GetText();  
    std::vector<EStringPair> components = codes[index]. GetComponentStrings();  
}
```

15. EasyBarcode2

15.1. Reading a Bar Code

Functional Guide | Reference: [Read](#), [SetMaxNumCodes](#), [GetDecodedString](#)

```
////////////////////////////////////  
//This code snippet shows how to read bar codes //  
////////////////////////////////////  
  
// Image constructor  
EImageBW8 srcImage;  
  
// Bar code reader constructor  
EasyBarcode2::EBarcodeReader reader;  
  
// Set the max number of bar codes to find  
reader.SetMaxNumCodes(...);  
  
// Read the barcodes in the source image  
std::vector<EasyBarcode2::EBarcode> results = reader.Read(srcImage);  
  
// Get decoded string  
std::string decodedString = results[0].GetDecodedString();
```

15.2. Reading a Bar Code of a Specific Symbology

Functional Guide | Reference: [Read](#), [DisableAllSymbologies](#), [EnableSymbology](#), [GetDecodedString](#)

```
////////////////////////////////////  
// This code snippet shows how to read bar codes //  
// of a specific symbology // //  
////////////////////////////////////  
  
// Image constructor  
EImageBW8 srcImage;  
  
// Bar code reader constructor  
EasyBarcode2::EBarcodeReader reader;  
  
// Set the max number of bar codes to find  
reader.SetMaxNumCodes(...);  
  
// Set symbology to use  
reader.DisableAllSymbologies();  
reader.EnableSymbology(...);  
  
// Read the barcodes in the source image  
std::vector<EasyBarcode2::EBarcode> results = reader.Read(srcImage);
```

```
// Get decoded string
std::string decodedString = results[0].GetDecodedString();
```

15.3. Reading a Grid of Bar Codes

Functional Guide | Reference: [Read](#), [EBarCodeGrid](#)

```
////////////////////////////////////
// This code snippet shows how to read bar codes that are //
// disposed in a 5 by 3 grid with 10% overlap between grid //
// cells //
////////////////////////////////////

EImageBW8 srcImage;
ERectangleRegion gridRegion;
EasyBarCode2::EBarCodeReader reader;

// Reading succeeds
EasyBarCode2::EBarCodeGrid grid = reader.Read(srcImage, gridRegion, 3, 5, 0.1f);

std::vector<EasyBarCode2::EBarCode> codesMiddleCell = grid.GetResults(1, 2);
```

15.4. Learning a Bar Code

Functional Guide | Reference: [Read](#), [Learn](#)

```
////////////////////////////////////
// This code snippet shows how to learn //
// from a given set of images //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// Set of images that are close to srcImage
std::vector<EImageBW8> learningImages;

// Bar code reader constructor
EasyBarCode2::EBarCodeReader reader;

// Reading fails
// std::vector<EasyBarCode2::EBarCode> barcodesFail = reader.Read(srcImage);

// Learns the learningImages
reader.Learn(learningImages);

// Reading succeeds
std::vector<EasyBarCode2::EBarCode> barcodes = reader.Read(srcImage);
```

15.5. Grading a Bar Code

Functional Guide | Reference: [Read](#), [SetComputeGrading](#), [GetGradingParameters](#)

```
////////////////////////////////////
// This code snippet shows how to compute //
// the ISO15416 grading of a barcode //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// Bar code reader constructor
EasyBarcode2::EBarcodeReader reader;

// Enables grading computation
reader.SetComputeGrading(true);

// Read the image and retrieve the computed grade
std::vector<EasyBarcode2::EBarcode> barcodes = reader.Read(srcImage);
if (!barcodes.empty())
{
    EasyBarcode2::EBarcodeGradingParameters grades = barcodes[0].GetGradingParameters();

    // global grade on a range from 0 to 40
    grades.GlobalGrade;

    // global grade on a range from F to A
    EasyBarcode2::EBarcodeGradingParameters::ConvertToAlphabeticGrade(grades.GlobalGrade);
}
```

16. EasyMatrixCode

16.1. Reading a Data Matrix Code

Functional Guide | Reference: [Read](#), [GetDecodedString](#)

```
////////////////////////////////////  
// This code snippet shows how to read a data matrix code //  
// and retrieve the decoded string. //  
////////////////////////////////////  
  
// Image constructor  
EImageBW8 srcImage;  
  
// Matrix code reader constructor  
EMatrixCodeReader reader;  
  
// Matrix code constructor  
EMatrixCode mxCode;  
  
// String for the decoded information  
std::string result;  
  
// ...  
  
// Read the source image  
mxCode = reader.Read(srcImage);  
  
// Retrieve the decoded string  
result = mxCode.GetDecodedString();
```

16.2. Learning a Data Matrix Code

Functional Guide | Reference: [SetLearnMaskElement](#), [Learn](#), [Read](#), [GetDecodedString](#)

```
////////////////////////////////////  
// This code snippet shows how to learn a given data matrix //  
// code type (except its flipping status), perform the //  
// reading and retrieve the decoded string. //  
////////////////////////////////////  
  
// Images constructor  
EImageBW8 model;  
EImageBW8 srcImage;  
  
// Matrix code reader constructor  
EMatrixCodeReader reader;  
  
// Matrix code constructor  
EMatrixCode mxCode;  
  
// String for the decoded information
```

```

std::string result;

// ...

// Tell the reader not to take the flipping into account when learning
reader.SetLearnMaskElement(ELearnParam_Flipping, false);

// Learn the model
reader.Learn(model);

// Read the source image
mxCode = reader.Read(srcImage);

// Retrieve the decoded string
result = mxCode.GetDecodedString();

```

16.3. Tuning the Search Parameters

Functional Guide | Reference: [GetSearchParams](#), [ClearLogicalSize](#), [AddLogicalSize](#), [ClearFamily](#), [AddFamily](#), [Read](#), [GetDecodedString](#)

```

////////////////////////////////////
// This code snippet shows how to explicitly specify the data //
// matrix code logical size and family, perform the reading //
// and retrieve the decoded string. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// Matrix code reader constructor
EMatrixCodeReader reader;

// Matrix code constructor
EMatrixCode mxCode;

// String for the decoded information
std::string result;

// ...

// Remove the default logical sizes
reader.GetSearchParams().ClearLogicalSize();

// Add the 15x15 and 17x17 logical sizes
reader.GetSearchParams().AddLogicalSize(ELogicalSize_15x15);
reader.GetSearchParams().AddLogicalSize(ELogicalSize_17x17);

// Remove the default families
reader.GetSearchParams().ClearFamily();

// Add the ECC050 family
reader.GetSearchParams().AddFamily(EFamily_ECC050);

// Read the source image
mxCode = reader.Read(srcImage);

// Retrieve the decoded string
result = mxCode.GetDecodedString();

```


16.4. Grading a Data Matrix Code

Functional Guide | Reference: [Read](#), [GetComputeGrading](#), [GetAxialNonUniformityGrade](#), [GetContrastGrade](#), [GetPrintGrowthGrade](#), [GetUnusedErrorCorrectionGrade](#)

```
////////////////////////////////////  
// This code snippet shows how to read a data matrix code //  
// and retrieve its print quality grading.           //  
////////////////////////////////////  
  
// Image constructor  
EImageBW8 srcImage;  
  
// Matrix code reader constructor  
EMatrixCodeReader reader;  
  
// Matrix code constructor  
EMatrixCode mxCode;  
  
// ...  
  
// Enable grading computation  
reader.SetComputeGrading(TRUE);  
  
// Read the source image  
mxCode = reader.Read(srcImage);  
  
// Retrieve the print quality grading  
int axialNonUniformityGrade= mxCode.GetAxialNonUniformityGrade();  
int contrastGrade= mxCode.GetContrastGrade();  
int printGrowthGrade= mxCode.GetPrintGrowthGrade();  
int unusedErrorCorrectionGrade= mxCode.GetUnusedErrorCorrectionGrade();
```

17. EasyMatrixCode2

17.1. Reading Data Matrix Codes

Functional Guide | Reference: [Read](#), [SetMaxNumCodes](#), [GetDecodedString](#)

```
////////////////////////////////////  
// This code snippet shows how to read data matrix codes //  
// and retrieve the decoded string. //  
////////////////////////////////////  
namespace EMC2 = Euresys::Open_eVision_x_x::EasyMatrixCode2;  
// Load an image  
EImageBW8 image;  
image.Load("image.bmp");  
// Prepare a matrix code reader  
EMC2::EMatrixCodeReader reader;  
// Let the reader know that there are no more than 3 codes in the image  
reader.SetMaxNumCodes(3);  
// Read the source image  
reader.Read(image);  
// Retrieve the detected codes  
std::vector<EMC2::EMatrixCode> codes = reader.GetReadResults();  
// Retrieve the decoded string for the first code  
std::string result = codes[0].GetDecodedString();
```

17.2. Learning a Data Matrix Code

Functional Guide | Reference: [Read](#), [Learn](#), [GetDecodedString](#)

```
////////////////////////////////////  
// This code snippet shows how to learn from a given image, //  
// perform the reading and retrieve the decoded string. //  
////////////////////////////////////  
namespace EMC2 = Euresys::Open_eVision_x_x::EasyMatrixCode2;  
  
// Load an image  
EImageBW8 image;  
image.Load("image.bmp");  
  
// Prepare a matrix code reader  
EMC2::EMatrixCodeReader reader;  
  
// Learn from this image  
reader.Learn(image);  
  
// Read the codes in this image  
reader.Read(image);  
  
// Retrieve the detected codes  
std::vector<EMC2::EMatrixCode> codes = reader.GetReadResults();
```

```
// Retrieve the decoded string of the first code
std::string result = codes[0].GetDecodedString();
```

17.3. Reading a Grid of Matrix Codes

Functional Guide | Reference: [Read](#), [EMatrixCodeGrid](#)

```
////////////////////////////////////
// This code snippet shows how to read matrix codes that are //
// disposed in a 5 by 3 grid with 10% overlap between grid //
// cells //
////////////////////////////////////

EImageBW8 srcImage;
ERectangleRegion gridRegion;
EMC2::EMatrixCodeReader reader;

// Reading succeeds
EMC2::EMatrixCodeGrid grid = reader.Read(srcImage, gridRegion, 3, 5, 0.1f);

std::vector<EMC2::EMatrixCode> codesMiddleCell = grid.GetResults(1, 2);
```

17.4. Grading a Data Matrix Code

Functional Guide | Reference: [Read](#), [SetComputeGrading](#)

```
////////////////////////////////////
// This code snippet shows how to read a data matrix code //
// and retrieve its print quality grades. //
////////////////////////////////////
namespace EMC2 = Euresys::Open_eVision_x_x::EasyMatrixCode2;
// Load an image
EImageBW8 image;
image.Load("image.bmp");
// Prepare a matrix code reader
EMC2::EMatrixCodeReader reader;
// Tell the reader to compute grades for the read codes
reader.SetComputeGrading(true);
// Read the codes in this image
reader.Read(image);
// Retrieve the detected codes
std::vector<EMC2::EMatrixCode> codes = reader.GetReadResults();
// Retrieve the SemiT10 grades of the first code
EMatrixCodeSemiT10GradingParameters semiT10Grades = codes[0].GetSemiT10GradingParameters();
// Retrieve specific grade values
float cellDefects = semiT10Grades.CellDefects;
float symbolContrast = semiT10Grades.SymbolContrast;
float unusedErrorCorrection = semiT10Grades.UnusedErrorCorrection;
```

17.5. Asynchronous Processing

```

////////////////////////////////////
// This code snippet shows how to read data matrix codes asynchronously //
// from three separate images. //
// The code in this snippet is valid for C++11 and newer. //
////////////////////////////////////

#include <thread>
#include <atomic>
namespace EMC2 = Euresys::Open_eVision_x_x::EasyMatrixCode2;
// create a subroutine that reads the codes from an image
void Read(EImageBW8& image, EMC2::EMatrixCodeReader& reader, std::vector<EMC2::EMatrixCode>& codes,
std::atomic<bool>& finished)
{
    // read the codes in this image
    reader.Read(image);

    // extract the results
    codes = reader.GetReadResults();

    // notify that the reader has finished
    finished = true;
}
int main()
{
    // Prepare three images
    EImageBW8 img1, img2, img3;

    // Prepare three matrix code readers
    EMC2::EMatrixCodeReader reader1, reader2, reader3;

    // Prepare three vectors of matrix code instances
    std::vector<EMC2::EMatrixCode> codes1, codes2, codes3;

    // Prepare three booleans to track the thread progress
    std::atomic<bool> finished1, finished2, finished3;

    // Load the three images
    img1.Load("image1.bmp");
    img2.Load("image2.bmp");
    img3.Load("image3.bmp");

    // Set the progress trackers to false
    finished1 = false;
    finished2 = false;
    finished3 = false;

    // Launch three threads to read the codes in each image
    // the threads will run in the background.
    std::thread thr1 = std::thread([&]{ Read(img1, reader1, codes1, finished1); });
    std::thread thr2 = std::thread([&]{ Read(img2, reader2, codes2, finished2); });
    std::thread thr3 = std::thread([&]{ Read(img3, reader3, codes3, finished3); });

    // Wait until one of the threads has finished
    while (!(finished1 || finished2 || finished3))
        std::this_thread::sleep_for(std::chrono::milliseconds(5));

    // Here, we manually stop all code readers, they will stop processing
    // even if they have not yet found the codes in the image
    reader1.StopProcess();
    reader2.StopProcess();
}

```

```
reader3.StopProcess();

// wait for the threads to completely finish before continuing
thr1.join();
thr2.join();
thr3.join();

return 0;
}
```

18. EasyQRCode

18.1. Reading QR Codes

Functional Guide | Reference: [Read](#)

```

////////////////////////////////////
// This code snippet shows how to read a QR code //
// and retrieve the decoded data.                //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// QR code reader constructor
EQRCodeReader reader;

// ...

// Read
std::vector<EQRCode> qrCodes = reader.Read(srcImage);

```

18.2. Reading a Grid of QR Codes

Functional Guide | Reference: [Read](#), [EQRCodeGrid](#)

```

////////////////////////////////////
// This code snippet shows how to read QR codes that are //
// disposed in a 5 by 3 grid with 10% overlap between grid //
// cells                                                //
////////////////////////////////////

EImageBW8 srcImage;
ERectangleRegion gridRegion;
EQRCodeReader reader;

// Reading succeeds
EQRCodeGrid grid = reader.Read(srcImage, gridRegion, 3, 5, 0.1f);

std::vector<EQRCode> codesMiddleCell = grid.GetResults(1, 2);

```

18.3. Grading a QR Code

Functional Guide | Reference: [Read](#), [SetComputeGrading](#)

```

////////////////////////////////////
// This code snippet shows how to read a QR code //
// and retrieve its print quality grades           //

```

```

////////////////////////////////////
// Load an image
EImageBW8 image;
image.Load("image.bmp");

// Prepare a qr code reader
EQRCoder reader;

// Tell the reader to compute grades for the codes read
reader.SetComputeGrading(true);

// Read the codes in this image
std::vector<EQRCoder> codes = reader.Read(image);

// Retrieve the detected codes
// Retrieve the ISO15415 grades of the first code
EQRCoderIso15415GradingParameters grades = codes[0].GetIso15415GradingParameters();

// Retrieve the scan grade of the code
float scanGrade = grades.ScanGrade;

```

18.4. Retrieving Information of a QR Code

Functional Guide | Reference: [Read](#), [GetVersion](#), [GetModel](#), [GetGeometry](#)

```

////////////////////////////////////
// This code snippet shows how to read a QR code //
// and retrieve the associated information. //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// QR code reader constructor
EQRCoder reader;

// ...

// Read
std::vector<EQRCoder> qrCodes = reader.Read(srcImage);

// Retrieve version, model and position information
// of the first QR code found, if one was found
if (qrCodes.size() > 0)
{
    int version = qrCodes[0].GetVersion();
    EQRCoderModel model = qrCodes[0].GetModel();
    EQRCoderGeometry geometry = qrCodes[0].GetGeometry();
}

```

18.5. Tuning the Search Parameters

Functional Guide | Reference: [Read](#), [GetDecodedString](#), [SetSearchedModels](#), [SetMaximumVersion](#), [SetMinimumIsotropy](#)

```

////////////////////////////////////
// This code snippet shows how to read a QR code //
// and retrieve the decoded data after setting a //
// number of search parameters.                //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// QR code reader constructor
EQRCodeReader reader;

// ...

// Set the search parameters
reader.SetMaximumVersion(7);
reader.SetMinimumIsotropy(0.9f);

// Set the searched models
std::vector<EQRCodeModel> models;
models.push_back(EQRCodeModel_Model12);
reader.SetSearchedModels(models);

// Read
std::vector<EQRCode> qrCodes = reader.Read(srcImage);

// Retrieve the decoded string in best guess mode of the first QR code found
string decodedString = qrCodes[0].GetDecodedString(EByteInterpretationMode_Auto);

```

18.6. Retrieving the Decoded String (Simple)

Functional Guide | Reference: [Read](#), [GetDecodedString](#)

```

////////////////////////////////////
// This code snippet shows how to read a QR code //
// and retrieve the decoded string.                //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// QR code reader constructor
EQRCodeReader reader;

// ...

// Read
std::vector<EQRCode> qrCodes = reader.Read(srcImage);

// Retrieve the data of the first QR code found in best guess mode
string decodedString = qrCodes[0].GetDecodedString(EByteInterpretationMode_Auto);

```

18.7. Retrieving the Decoded String (Safe)

Functional Guide | Reference: [Read](#), [GetDecodedString](#)


```

////////////////////////////////////
// This code snippet shows how to read a QR code //
// and retrieve the decoded string //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// QR code reader constructor
EQRCodeReader reader;

// ...

// Read
std::vector<EQRCode> qrCodes = reader.Read(srcImage);

// Retrieve the data of the first QR code found
string decodedString = "";
try
{
    // The QR Code can be fully decoded without user input
    decodedString = qrCodes[0].GetDecodedString();
}
catch(EException exc)
{
    // Handle the exception
    ...
    // The QR Code cannot be fully decoded without user input
    // use hexadecimal byte interpretation
    decodedString = qrCodes[0].GetDecodedString(EByteInterpretationMode_Hexadecimal);
}

```

18.8. Retrieving the Decoded Data (Advanced)

Functional Guide | Reference: [Read](#), [GetDecodedStream](#), [GetDecodedData](#), [GetCodingMode](#), [GetDecodedStreamParts](#)

```

////////////////////////////////////
// This code snippet shows how to read a QR code //
// and retrieve its coding mode, //
// the raw bit stream and the data part by part //
////////////////////////////////////

// Image constructor
EImageBW8 srcImage;

// QR code reader constructor
EQRCodeReader reader;
// ...

// Read
std::vector<EQRCode> qrCodes = reader.Read(srcImage);

// Retrieve the data stream of the first QR code found
EQRCodeDecodedStream stream = qrCodes[0].GetDecodedStream();

// Retrieve the coding mode and the raw bit stream of the first QR code found
EQRCodeCodingMode codingMode = stream.GetCodingMode();
vector<UINT8> bitstream = stream.GetRawBitstream();

```

```
// Retrieve the encoding and the decoded data of each part of the first QR code found
vector<EQRCodedStreamPart> parts = stream.GetDecodedStreamParts();
for(unsigned int i = 0 ; i < parts.size(); ++i)
{
    // Retrieve encoding
    EQRCodedStreamPart encoding = parts[i].GetEncoding();

    // Retrieve the decoded data
    vector<UINT8> decodedData = parts[i].GetDecodedData();

    // Interpret the decoded data based on the retrieved encoding
    ...
}
```

19. Easy3D

19.1. Using EFilters to Remove the Noise on a ZMap Based on the Standard Deviation

```

////////////////////////////////////
// The code below removes pixels with a standard deviation //
// higher than a defined threshold in a ZMap.           //
////////////////////////////////////

// Load the ZMap data
EZMap16 zmap;
zmap.Load("");

// Compute the filtered ZMap. The new ZMap is called filteredZmap
// The size of the kernel is 7x7, the threshold is 30.0
EZMap16 filteredZmap;
filteredZmap.SetSize(zmap);

EFilters::RemoveNoise(zmap, filteredZmap, ENoiseRemovalMethod_HighStandardDeviation, 3, 30.0, 0.0);

```

19.2. Using EFilters to Remove the Noise on a ZMap Based on the Derivation from Neighborhood

```

////////////////////////////////////
// The code below first applies a low pass filter to a ZMap. //
// It then removes from the result the pixels showing a deviation //
// from the neighborhood larger than the defined threshold. //
////////////////////////////////////

// Load the ZMap data
EZMap16 zmap;
zmap.Load("");

// Compute the filtered ZMap. The new ZMap is called averagedZMap
// The size of the kernel is 7x7, the threshold is 30.0
EZMap16 averagedZMap;
averagedZMap.SetSize(zmap);

EStatistics::ComputeAverageMap(zmap, averagedZMap, 3, 0.2f);

// Compute the filtered ZMap. From averagedZMap, compute filteredZMap
// The size of the kernel is 31x31, the threshold is 20.0
EZMap16 filteredZMap;
filteredZMap.SetSize(zmap);

EFilters::RemoveNoise(averagedZMap, filteredZMap, ENoiseRemovalMethod_AbsoluteDifferenceFromMean, 15, 20.0, 0.2f);

```

19.3. Reducing the Size of a Cloud with Random Decimation

```

////////////////////////////////////
// The code reduce the size of a cloud by removing points randomly //
////////////////////////////////////

EPointCloud pc;
pc.Load("");

// Explicitly decimate the point cloud to keep 5000 points
ERandomDecimator decimator(5000);
EPointCloud pcDecimated;

decimator.Decimate(pc, pcDecimated);

```

19.4. Reducing the Size of a Cloud with Grid Decimation

```

////////////////////////////////////
// The code reduce the size of a cloud by removing points //
// to keep at most one per cell of a regular grid //
////////////////////////////////////

EPointCloud pc;
pc.Load("");

// Explicitly decimate the point cloud to keep
// one point in every cube of 10*10*10
EGridDecimator decimator(10.f);
EPointCloud pcDecimated;

decimator.Decimate(pc, pcDecimated);

```

19.5. Using Photometric Stereo

```

////////////////////////////////////
// The code shows how to use Photometric Stereo //
// from calibration to retrieve the results //
////////////////////////////////////

EPhotometricStereoImager photometricStereo;

std::vector<EImageBW8> calibrationImages;
// Load calibration images (Todo)
std::vector<EROIBW8> calibrationROIs;
// Set the calibration ROIs (Todo)

// Calibrate
float score = photometricStereo.CalibrateFromSphere(calibrationROIs);

```

```

std::vector<EImageBW8> objectImages;
// Load object images in the same order than the calibration images/angles (Todo)

std::vector<EROIBW8> objectROIs;
// Set the object ROIs (Todo)

// Compute
photometricStereo.Compute(objectROIs);

// Retrieve the results
EImageC24 normals = photometricStereo.GetNormals();
EImageBW8 albedos = photometricStereo.GetAlbedos(Easy3D::EPhotometricStereoContrast_HighContrast);
EImageBW8 gradientsX = photometricStereo.GetGradientsX();
EImageBW8 gradientsY = photometricStereo.GetGradientsY();
EImageBW8 gaussianCurvatures = photometricStereo.ComputeGaussianCurvatures(Easy3D::EPhotometricStereoContrast_
HighContrast);
EImageBW8 meanCurvatures = photometricStereo.ComputeMeanCurvatures(Easy3D::EPhotometricStereoContrast_
HighContrast);
EZMap8 heightMap = photometricStereo.ComputeHeightMap();

```

19.6. Using Flat Images to Improve Photometric Stereo

```

////////////////////////////////////
// The code shows how to use flat images to //
// improve photometric stereo's results    //
////////////////////////////////////

EPhotometricStereoImager photometricStereo;
// calibrate imager or sets its angles (Todo)

// Load flat images in the same order than the calibration images/angles (Todo)

std::vector<EROIBW8> flatROIs;
// Set the flat images ROIs (Todo)

// Configure flat images, this could optionally be done with a dark image as well
photometricStereo.ConfigureNonUniformLightingCorrection(flatROIs);

std::vector<EROIBW8> objectROIs;
// Set the object ROIs (Todo)

// Perform one or more computations, each will use the flat images (Todo)
photometricStereo.Compute(objectROIs);

// Optional: non uniform lighting correction could be disabled or (re-)enabled
// using SetEnableNonUniformLightingCorrection

```

19.7. Performing Plane Leveling on Point Clouds

```

////////////////////////////////////
// The code shows how to perform plane leveling //
// on point clouds                               //
////////////////////////////////////

// find the reference plane on the point cloud
E3DPlane ref_plane;
EPointCloud point_cloud;

// define the ground plane as the plane Z=0
E3DPlane ground_plane(E3DPlane::ZPlane());

// get the transformation that moves
// the reference plane to the ground plane
E3DTransformMatrix transformation;
transformation = ref_plane.GetTransformationTo(ground_plane);

// apply the transformation to the point cloud
EAffineTransformer transformer;
transformer.ApplyMatrix(transformation, point_cloud);

```

19.8. Using an ERegion to Crop a ZMap

```

////////////////////////////////////
// The code shows how to perform cropping on a zmap //
// on point clouds                               //
////////////////////////////////////

EZMap8 zmap;
zmap.Load("");

// prepare an ERegion
std::vector<EPoint> points = { EPoint(90, 76), EPoint(432, 87),
EPoint(466, 91), EPoint(502, 122), EPoint(513, 169),
EPoint(485, 218), EPoint(436, 231), EPoint(86, 215) };
EPolygonRegion region(points); // could be any type of ERegion

EZMap8 zmapCropped(zmap.GetWidth(), zmap.GetHeight());
EUtils::Copy(zmap.GetUndefinedValue(), zmapCropped);
EUtils::Copy(zmap, region, zmapCropped);

```

19.9. Add an Attribute to an EPointCloud with Initial Data

```

////////////////////////////////////
// The code shows how to add an attribute //
// to a cloud when you already have the data //
////////////////////////////////////

EPointCloud cloud;
std::vector<EC24A> data;

```

```
// case 1: data is Color, Normal, Intensity, Texture, Index, Confidence or Distance
cloud.FillAttributeBuffer(E3DAttribute_Color, data);

// case 2: data is something else
int attributeOffset = cloud.AddCustomAttributeBuffer(data);
```

19.10. Add an Attribute to an EPointCloud without Initial Data

```
////////////////////////////////////
// The code shows how to add an attribute      //
// to a cloud when you don't have the data    //
////////////////////////////////////

EPointCloud cloud;
EC24A defaultValue;

// case 1: data is Color, Normal, Intensity, Texture, Index, Confidence or Distance
cloud.AllocateAttributeBuffer(E3DAttribute_Color, defaultValue);

// case 2: data is something else
int attributeOffset = cloud.AllocateCustomAttributeBuffer(defaultValue);
```

19.11. Retrieve an Attribute from an EPointCloud

```
////////////////////////////////////
// The code shows how to retrieve an attribute //
// from a cloud //
////////////////////////////////////

EPointCloud cloud;
const EC24A* data;

// case 1: data is Color, Normal, Intensity, Texture, Index, Confidence or Distance
data = static_cast<const EC24A*>(cloud.GetAttributeBuffer(E3DAttribute_Color));

// case 2: data is something else
int attributeOffset = 17; // value retrieved when we initialized the attribute
data = static_cast<const EC24A*>(cloud.GetAttributeBuffer(attributeOffset));
```

20. Easy3DObject

20.1. Extracting 3D Objects with a Selection Criterion

```
// EZmap constructor
EZMap8 zMap;

// Extractor constructor
E3DObjectExtractor extractor;

// Setting a selection criterion
extractor.SetWidthRange(EFloatRange(10, 500));

// Extracts the objects from the EZMap
int regionNB = extractor.Extract(zMap);

// Retrieve the extracted objects
std::vector<E3DObject> objects = extractor.GetObjects();
```

20.2. Inspecting a Feature from the List of E3DObjects

```
// Get the list of E3DObjects
std::vector<E3DObject> objects = extractor.GetObjects();

// Get the volume of the first object
float volume = objects[0].GetVolume();

// Get the ERectangleRegion of the last (the largest) object
ERectangleRegion region = objects.back().GetRectangleRegion();
```

20.3. Drawing a 2D Feature from the List of E3DObjects

```
// Get the list of E3DObjects
std::vector<E3DObject> objects = extractor.GetObjects();

// Get a render context
HDC drawHDC;

// Draw the ERegion of each object
```



```
int nObjects = (int)objects.size();
for (int i = 0; i < nObjects; i++)
    objects[i].Draw(drawHDC, E3DObjectFeature_ERegion, ERGBColor(0, 255, 0));
```

20.4. Drawing 3D Features from a List of E3DObjects

```
        // Get the list of E3DObjects
std::vector<E3DObject> objects = extractor.GetObjects();

// Register the list of E3DObjects to the 3D viewer
E3DViewer viewer3D(0,0,640,480);
viewer3D.Register3DObjects(objects);

// Define and use a render style for the ReferenceTopPosition feature
ERenderStyle renderStyle;
renderStyle.pointRGB = EC24A(100, 0, 0);
viewer3D.SetFeatureStyleForAll3DObjects(renderStyle, E3DObjectFeature_ReferenceTopPosition);

// Set a different rendering color for the first object
ERenderStyle selectedRenderStyle;
selectedRenderStyle.pointRGB = EC24A(255, 255, 0);
viewer3D.SetFeatureStyleFor3DObject(0, selectedRenderStyle, E3DObjectFeature_ReferenceTopPosition);

// Enable the display of the TopZPosition feature
viewer3D.ShowFeatureForAll3DObjects(E3DObjectFeature_ReferenceTopPosition);
```

21. Easy3DMatch

21.1. E3DAligner Minimal Code

```

////////////////////////////////////
// This code snippet shows how to compute the //
// alignment between a sample and a cad reference.//
////////////////////////////////////

// load the reference mesh and define the pose
Easy3D::E3DAligner aligner;
Easy3D::EMesh cad;
cad.Load("...");
float azimuthReference = 0.f, elevationReference = 90.f;
aligner.SetReference(cad, azimuthReference, elevationReference);

// load the sample
Easy3D::EPointCloud sample;
sample.Load("...");
float azimuthSample = 0.f, elevationSample = 90.f;

// perform alignment
Easy3D::E3DAlignment alignment = aligner.Align(sample, azimuthSample, elevationSample);

```

21.2. E3DAligner Reprojection Plane

```

////////////////////////////////////
// This code snippet shows how to set the //
// reprojection plane when performing alignment. //
////////////////////////////////////

// load the reference mesh and define the pose
Easy3D::E3DAligner aligner;
Easy3D::EMesh cad;
cad.Load("...");
Easy3D::E3DPlane refPlane(Easy3D::E3DPoint(0, 0, 1), 0);
aligner.SetReference(cad, refPlane);

// define the reprojection plane
bool userKnowsPlaneAZEL = false; // depending on the user
if (userKnowsPlaneEquation)
{
    Easy3D::E3DPlane reprojectionPlane(Easy3D::E3DPoint(0, 0, -1), -15);
    aligner.SetScanReprojectionPlane(reprojectionPlane);
}
else
{
    Easy3D::EPointCloud cloud;
    cloud.Load("...");
    bool objectAbovePlane = true; // is the object above the plane on the cloud
    aligner.SetFlatScan(cloud, objectAbovePlane);
}

```

```

}

// load the sample
Easy3D::EPointCloud sample;
sample.Load("...");
float azimuthSample = 0.f, elevationSample = 90.f;

// perform alignment
Easy3D::E3DAlignment alignment = aligner.Align(sample, azimuthSample, elevationSample);

```

21.3. E3DAlignment Align Sample

```

////////////////////////////////////
// This code snippet shows how to apply the //
// transformation of the E3DAlignment to the //
// sample to overlap it on the reference //
////////////////////////////////////

// perform alignment (see previous examples)
Easy3D::E3DAlignment alignment;
EPointCloud sample;

// align sample on reference
Easy3D::EPointCloud alignedSample;
Easy3D::EAffineTransformer::ApplyMatrix(alignment.GetPose(), sample, alignedSample);

```

21.4. E3DComparer Minimal Sample

```

////////////////////////////////////
// This code snippet shows how to compare a sample //
// with a golden scan reference. //
////////////////////////////////////

// load the reference golden scan and set reference
Easy3D::E3DComparer comparer;
Easy3D::EPointCloud cloud;
cloud.Load("...");
comparer.SetPointCloudReference(cloud);

// set thresholds
float distanceThresh = .2f, areaThresh = 1.f;
comparer.SetAnomalyThresholds(distanceThresh, areaThresh);

// prepare data structures (optional)
comparer.PrepareReference();

// load the sample and perform comparison
Easy3D::EPointCloud sample;
sample.Load("...");
comparer.Compare(sample);

// compute anomalies
std::vector<Easy3D::E3DAnomaly> anomalies = comparer.ComputesAnomalies();

// TODO: if (anomalies.size() != 0u): an anomaly was detected: inspect the sample manually? throw it away?

```

```
// get cloud to inspect it manually
Easy3D::EPointCloud visualisationCloud;
comparer.GetComparisonPointCloud(visualisationCloud);
```

21.5. E3DComparer Advanced Sample

```
////////////////////////////////////
// This code snippet shows how to set the options //
// when comparing two elements with E3DComparer. //
////////////////////////////////////

// load the reference golden scan and set reference
Easy3D::E3DComparer comparer;
Easy3D::EPointCloud cloud;
cloud.Load("...");
comparer.SetPointCloudReference(cloud);

// set thresholds
float distanceThresh = .2f, areaThresh = 1.f;
float hystDistanceThresh = 1.5f, hystAreaThresh = .5f;
comparer.SetAnomalyThresholds(distanceThresh, areaThresh);
comparer.SetAnomalyHysteresis(hystDistanceThresh, hystAreaThresh); // defined relatively to base thresholds

// set ROIs
std::vector<Easy3D::E3DBox> rois = { Easy3D::E3DBox(15, 15, 15) };
comparer.SetROI(rois);
std::vector<Easy3D::E3DBox> dontCare = { Easy3D::E3DBox(5, 5, 5) };
comparer.SetDontCare(dontCare);
std::vector<Easy3D::E3DBox> noExtraMaterial = { Easy3D::E3DBox(Easy3D::E3DPoint(10, 15, 20), 0, 0, 0, 5, 5, 5) };
comparer.SetNoExtraMaterial(noExtraMaterial);

// prepare data structures (optional)
comparer.PrepareReference();

// load the sample and perform comparison
Easy3D::EPointCloud sample;
sample.Load("...");
comparer.Compare(sample);

// compute anomalies
std::vector<Easy3D::E3DAnomaly> anomalies = comparer.ComputesAnomalies();

// TODO: if (anomalies.size() != 0u): an anomaly was detected: inspect the sample manually? throw it away?

// get cloud to inspect it manually
Easy3D::EPointCloud visualisationCloud;
comparer.GetComparisonPointCloud(visualisationCloud);
```

21.6. E3DMatcher Minimal Sample

```
////////////////////////////////////
// This code snippet shows how to match a sample //
// with a golden scan reference. //
////////////////////////////////////
```

```

////////////////////////////////////
// load the reference golden scan and set reference
Easy3D::E3DMatcher matcher;
Easy3D::EPointCloud reference;
float azimuthReference = 0.f, elevationReference = 90.f;
reference.Load("...");
matcher.SetReference(reference, azimuthReference, elevationReference);

// set thresholds
float distanceThresh = .2f, areaThresh = 1.f;
matcher.SetAnomalyThresholds(distanceThresh, areaThresh);

// prepare data structures (optional)
matcher.PrepareReference();

// load the sample and perform comparison
Easy3D::EPointCloud sample;
float azimuthSample = 0.f, elevationSample = -90.f;
sample.Load("...");
Easy3D::E3DMatch match = matcher.Match(sample, azimuthSample, elevationSample);
std::vector<Easy3D::E3DAnomaly> anomalies = match.GetAnomalies();

// TODO: if (anomalies.size() != 0u): an anomaly was detected: inspect the sample manually? throw it away?

// get cloud to inspect it manually
Easy3D::EPointCloud visualisationCloud;
matcher.GetComparisonPointCloud(visualisationCloud);

```

21.7. E3DMatcher Advanced Sample

```

////////////////////////////////////
// This code snippet shows how to set the options //
// when matching two elements with E3DMatcher. //
////////////////////////////////////

// load the reference golden scan and set reference
Easy3D::E3DMatcher matcher;
Easy3D::EPointCloud reference;
float azimuthReference = 0.f, elevationReference = 90.f;
reference.Load("...");
matcher.SetReference(reference, azimuthReference, elevationReference);

// use advanced comparison mode
matcher.SetComparisonDistanceMode(EComparisonDistanceMode_Advanced);

// ignore shadows
matcher.SetEnableMissingPointAsAnomaly(false);

// set thresholds
float distanceThresh = .2f, areaThresh = 1.f;
float hystDistanceThresh = 1.5f, hystAreaThresh = .5f;
matcher.SetAnomalyThresholds(distanceThresh, areaThresh);
matcher.SetAnomalyHysteresis(hystDistanceThresh, hystAreaThresh); // defined relatively to base thresholds

// retrieve reference poses (reference must have been set)
std::vector<Easy3D::EZMap8> referencePoseProjections;
matcher.RetrieveReferencePosesProjections(referencePoseProjections);

// set ROI on the left half of the object

```

```

ERectangleRegion roiRegion(0.f, 0.f, float(referencePoseProjections[0].GetWidth()) / 2.f, float
(referencePoseProjections[0].GetHeight()));
matcher.SetComparisonROI(&roiRegion);

// set No Extra material on the whole object
ERectangleRegion noExtraMatRegion(0.f, 0.f, float(referencePoseProjections[0].GetWidth()) / 2.f, float
(referencePoseProjections[0].GetHeight()));
matcher.SetComparisonNoExtraMaterial(&noExtraMatRegion);

// prepare data structures (optional)
matcher.PrepareReference();

// load the sample and perform comparison
Easy3D::EPointCloud sample;
float azimuthSample = 0.f, elevationSample = -90.f;
sample.Load("...");
Easy3D::E3DMatch match = matcher.Match(sample, azimuthSample, elevationSample);
std::vector<Easy3D::E3DAnomaly> anomalies = match.GetAnomalies();

// TODO: if (anomalies.size() != 0u):an anomaly was detected: inspect the sample manually? throw it away?

// get cloud to inspect it manually
Easy3D::EPointCloud visualisationCloud;
matcher.GetComparisonPointCloud(visualisationCloud);

```

21.8. EPointCloudMerger Sample

```

////////////////////////////////////
// This code snippet shows how to perform sensor fusion. //
////////////////////////////////////

// Calibration
Easy3D::EPointCloudMerger merger;
std::vector<EPointCloud> calibrationClouds; // TODO: load or grab
float calibrationObjectSize = 100.f; // size of an edge of the cube in the calibrationClouds
float calibrationScore = merger.Calibrate(calibrationClouds, calibrationObjectSize, true);

// Merging
std::vector<EPointCloud> clouds; // TODO: load or grab, must be in same order as CalibrationClouds
EPointCloud mergedCloud;

merger.Merge(clouds, mergedCloud);

```